



TRANS-CONTINENTAL GROUP LIMITED

Outdoor Furniture Covers

The life and good looks of your cover depend a great deal on the way you use and how you care for your cover. Even the most durable materials require a certain amount of care, and fabric covers are no exception. Following these suggestions and tips can preserve the life of a cover.

How to Protect Your Cover

- Use Fabric Guard to prevent permanent water-based or oil-based stains and to restore lost water repellency.
- During long periods of use, move your covered furniture to a covered area to prevent pooling of water and elongated UV exposure.

How to Clean Your Cover

- Shake off cover to rid it of debris
- Use a garden hose to rinse cover
- Use mild soap and warm water with sponge or bristle brush. For our Classic covers, use a Vinyl Protective Cleaner to prevent fading, cracking and premature aging.
- Use a towel to dry areas where moisture is present.
- Please do not machine wash your cover.

How to Fold and Store Your Cover

- Lay out your cover on a flat surface (i.e. a table or clean floor)
- Square up the cover by folding in all angled & elastic sides
- Fold the cover in half until it is at the desired size
- If your cover is going to be stored in a garage or shed, store it in a water-proof container