


How to Intall a Round Chimney Cap



There are three types of round chimney caps.



Cap A (Forever Round Slip In Cap) is made to slip inside a chimney flue, with a pressure fit. This cap will fit single wall stove pipe, masonry round clay pipe, flexible chimney lining systems and double wall chimney pipe. Just push it inside the chimney flue. Apply a bead of silicone adhesive for a secure fit. Please note the size of the cap is 1/8 of inch smaller than the size listed.

Cap B (Forever Masonry Round Cap) is made to slide over a masonry chimney clay flue. Measure the outside (O.D.) of the flue. Choose the appropriate size cap. Slide the cap over the clay flue tile and tighten the four set screws to the flue. **DO NOT** over tighten the screws. Over tightening the screws make cause the clay tile to crack.



Cap C (Forever Guard Cap) is made to slip inside a factory built double or triple wall chimney flue pipe, with a pressure fit. This cap will also fit single wall stove pipe, masonry round clay pipe and flexible chimney lining systems. Just push it inside the chimney flue. Apply a bead of silicone adhesive for a secure fit. Please note the size of the cap is 1/8 of inch smaller than the size listed.