

Installation Guide for the Garden Watering Wand

1. Before Installation

- **Inspect the Components:** Ensure that your GREEN MOUNT garden hose wand comes with all parts intact. You should have the wand itself with its handle, the adjustable sprayer head, and the hold - open clip at the front bottom of the handle. Check for any visible damages to the lightweight aluminum construction or the non - corrosive exterior.
- **Gather Tools:** You won't need many tools for this installation. A simple pair of pliers might be helpful if the connections are a bit tight, but usually, hand - tightening is sufficient.

2. Connecting the Watering Wand to the Hose

- **Locate the Hose Connector:** At the end of the watering wand, there is a connector designed to fit standard garden hoses. The connector is designed to be user - friendly for easy attachment.
- **Attach the Wand to the Hose:** Align the threads of the watering wand connector with those of the garden hose. Start turning the wand clockwise by hand to screw it onto the hose. Make sure to turn it firmly, but be careful not to overtighten as this could damage the threads. If you encounter resistance, use the pliers gently to give it a bit more torque, but again, don't overdo it.

3. Adjusting the Sprayer Patterns

- **Familiarize with the Adjustment Mechanism:** The GREEN MOUNT garden hose wand has 8 adjustable watering patterns. Locate the adjustment dial or mechanism on the sprayer head. This is usually a rotating or sliding part.
- **Select the Desired Pattern:** To change the pattern, simply rotate or slide the adjustment mechanism. For example, if you want to use the "flat" pattern for pressure washing debris off the patio, turn the adjustment until the sprayer is set to the flat pattern. The patterns are clearly marked on the sprayer head or in the product manual for easy identification.

4. Installing the Hold - Open Clip

- **Position the Clip:** The hold - open clip is located at the front bottom of the handle. It is designed to be easily installed. Place the clip in the designated groove or position on the handle.
- **Secure the Clip:** Once in position, make sure the clip is firmly in place. It should click or snap into position, ensuring that it can hold the trigger in the open position for continuous spraying, which is especially useful for those with arthritis or disabilities.

5. Testing the Watering Wand

- **Turn on the Water Supply:** Before using the watering wand for real, turn on the water supply at a low pressure first. This helps to check for any leaks at the connection between the hose and the watering wand.
- **Test Different Patterns:** Try out each of the 8 adjustable watering patterns. Test the “jet” pattern by aiming it across the yard, the “soaker” for potted plants, etc. This not only ensures that the patterns are working correctly but also gives you a feel for how the wand performs in different scenarios.
- **Check the Hold - Open Clip:** Use the hold - open clip to test continuous spraying. Make sure that the clip holds the trigger open securely and that the water flow remains consistent.