




SK19087C2 GRACIE ACCENT CABINET WITH 2 GLASS DOOR  
ASSEMBLY INSTRUCTIONS

Made In China



## Safety Information



### DANGER

- Keep small parts away from children during assembly.
- Read and follow instructions carefully.



### WARNING

- Read these instructions carefully and keep in a safe place.
- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- Small parts may present choking hazard prior to assembly.
- Do not place heavy objects on the glass top.
- Some assembly may involve attaching glass or mirrors.
- Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks.
- Never handle large pieces of glass or mirrors by yourself.



### CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.). Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- This product should only be used on a flat, level surface.

## Warranty

### 3 YEAR WARRANTY

#### WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

#### WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

## Customer Care


EMail:customercare@easygoodsliving.com

Customer Service Number:(725)298-8606


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


## PARTS LIST




TOP PANEL-1PC




LEFT SIDE PANEL-1PC




RIGHT SIDE PANEL-1PC




ADJUSTABLE SHELF-1PC




BOTTOM PANEL-1PC






LEFT SIDE DOOR-1PC



RIGHT SIDE DOOR-1PC





BACK PANEL-1PC

a 	b 	c 			
WOOD DOWEL-8PCS	CAM LOCK BOLT-8PCS	CAM LOCK-8PCS			
d 	e 	f 			
5/8" L ROUND HEAD SCREW-17PCS	MAGNET-1PC	HANDLE-2PC			
g 	h 	i 			
Ø5/32" X 5/8" BOLT-4PCS	1/2" L FLAT HEAD SCREW-8PCS	SHELF PIN-4PCS			
j 					
PLASTIC COVER-4PCS					
	 x2 RECTANGLE METAL PLATE	 x1 FLAT HEAD SCREW	 x1 PLASTIC ANCHOR	 x1 PLASTIC BAND	 x1 1-1/2" L FLAT HEAD SCREW
	ANTI-TIPPING HARDWARE PACKAGE				


NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.



NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL



NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

FIG 1




FIG 2







FIG 3




**FIG 4**



**FIG 5**



# FIG 6



**FIG 7**

