

Ashman Plastic Mesh Fence: Installation & Assembly Instructions

Thank you for choosing the **Ashman Plastic Mesh Fence**! This durable and versatile fencing solution is perfect for gardens, construction sites, animal enclosures, and more. Follow these simple steps for quick and secure installation.

Tools & Materials Needed

- Ashman Plastic Mesh Fence roll
- Zip ties, stakes, or metal/plastic posts (not included)
- Hammer or mallet (if using stakes)
- Scissors or utility knife (for trimming excess mesh)
- Gloves (optional, for handling sharp edges)

Step-by-Step Installation Guide

1. Unroll and Inspect the Fence

- Lay the fence flat on the ground along the desired perimeter.
- Ensure the mesh is free from twists or tangles before securing.

2. Secure the Starting Point

- **For Temporary Use (Stakes):**
 - Insert a stake at the beginning of the fence line.
 - Attach the mesh to the stake using zip ties or by weaving the stake through the mesh.
- **For Semi-Permanent Use (Posts):**
 - Install a sturdy post (wood, metal, or plastic) at the starting point.
 - Secure the mesh to the post using zip ties or fence clips.

3. Unroll and Align the Fence

- Slowly unroll the fence along the intended path, keeping it taut to avoid sagging.

- For curved areas, gently bend the mesh—it is flexible but may require additional stakes for support.

4. Secure the Fence at Intervals

- **Using Stakes:**
 - Place stakes every **3–5 feet** for stability.
 - Attach the mesh to each stake with zip ties or by weaving the stake through the mesh.
- **Using Posts:**
 - Space posts **6–10 feet apart** for a stronger hold.
 - Fasten the mesh tightly to each post.

5. Reinforce Corners and Ends

- Corners and endpoints bear the most tension—use extra stakes or posts for reinforcement.
- Double up on zip ties or use heavy-duty fasteners if needed.

6. Trim Excess Mesh (If Needed)

- If the fence is longer than needed, cut the mesh with scissors or a utility knife.
- Secure the trimmed end to a post or stake to prevent unraveling.

7. Final Check & Adjustments

- Walk along the fence to ensure it is securely fastened and properly aligned.
- Tighten any loose sections and add extra stakes if the fence sags.

Tips for Best Results

✓ For Animal Containment (Chickens, Rabbits, etc.):

- Bury the bottom **4–6 inches** of the mesh to prevent digging under.
- Use additional stakes in high-wind areas to prevent lifting.

✓ For Garden Protection (Deer, Rabbits):

- Ensure the fence is at least **4 feet tall** to deter jumping animals.