












GAMING CHAIR MODEL: TS36C






ASSEMBLY INSTRUCTIONS

Thank you for purchasing our product.



REV.HNG-1021-0

MAIN PARTS LIST				
A x1 Backrest 	B x1 Seat 	C x1 5-Leg star base 	D x1 Mechanism 	
E x1 Pneumatic lift cylinder 	F x5 Casters 	G-L x1 Left armrest  (Front)	G-R x1 Right armrest  (Front)	H x1 Headrest 
Sitting on the chair, not looking at it				


HARDWARE LIST				
PART	QTY	ITEM	USE IN	
I	4	M6x20	Mechanism to seat	
J	6	M6x30	Arms to Seat	
K	3	M8x20	Backrest to mechanism	
L	2	M6x20	Headrest to backrest	
	1	Allen Wrench	Steps 2, 3 and 4	

BEFORE YOU START THE ASSEMBLY, PLEASE READ THE FOLLOWING TIPS AND WARNINGS.

1 Do a quick inventory to make sure the package contains all the parts and hardware listed in the assembly instructions.




6 Make sure you understand which hardware will be used on each step. Using the wrong size of screw, bolt or pin might strip the threads or cause damage to the part in which it is being used.



2 Missing, damaged and defective parts can be replaced at no cost to you. Please refer to the last page in this manual.




7 To avoid misalignments, always leave the screws loose and tighten them until all pieces are positioned correctly.



3 The replacement parts service is limited to the 48 contiguous United States. If you reside in Alaska, Hawaii, Puerto Rico, U.S. territories or other countries, please contact the supplier from where the unit was purchased.



8 Do not overtighten or force the screws as they might break, strip, damage the threads of the holes or get stuck inside the part.



4 If during assembly you find an issue or need clarification, please contact our Customer Service for assistance. Please refer to the last page in this manual.



9 If the hole seems too big or too small for the screw, first make sure you are using the correct size of screw and that it's been installed in the correct hole. Test another of the same screw into the same hole, as well as test the screw onto different holes for the same part. If the hole still appears to be too small, do not force it, it needs replacing.


5 On each step read the instructions and analyze the illustrations thoroughly before proceeding to do the assembly.



ASSEMBLY STEPS

STEP 1

Insert the casters **F** into the legs of the base **C** using pressure, then place the gas lift **E** in the middle of the base.



STEP 2

Hardware


J



6 Pcs



Turn over the seat **B**, and assemble the armrests **G** in their respective sides with screws **J** as shown.



STEP 3

Hardware


I



4 Pcs



Assemble the mechanism **D** to the seat **B** with screws **I** making sure its spring knob faces towards the **FRONT** of the seat as shown.



STEP 4


Hardware

Insert the metal plate of the backrest **A** under the metal plate of the mechanism **D**, and secure it with screws **K** as shown.

K





3 Pcs



STEP 5

Put the seat over the base parts making sure the tip of the pneumatic lift **E** enters into the hole of the mechanism **D**.



STEP 6


Hardware

Attach the headrest **H** to the backrest **A** with screws **L**.

L




2Pcs



ALL DONE! Give yourself a nice pat on the back. You did a great job!

CHAIR'S FUNCTIONS

- ① Chairs' height: Pull UP the handle from the lever located under the seat. The chair goes down while sitting on it, or up if you lift your body.
- ② Backrest reclining: Pull the same lever OUT horizontally to unlock this function and allow free reclining. Push the lever IN to lock the backrest in any of its 2 reclining positions or while upright. To unlock and allow free reclining, pull the lever OUT again and push the backrest back a little to disengage.
- ③ Reclining tension: Turn the mechanism's knob in either direction to apply more or less tension. With less tension, the backrest reclining will feel easier.
- ④ Headrest functions: Move the headrest UP or DOWN to adjust its height. Tilt the headrest to adjust for comfort.
- ⑤ 3D armrest functions: Pull UP the button to adjust the armrests' height. The arm pads can pivot and move forward/back.



WARNINGS

- Do not exceed the indicated weight limit.
- Do not stand up on the chair or use it as ladder.
- Only one person at a time can sit on the chair.
- Do not use the chair if parts are damaged or if screws are loose or missing.
- Do not sit near the edge of the seat to avoid going beyond your balance point and falling off the chair, and always sit properly.
- If small children are sitting on the chair, do not leave them unattended.
- Do not allow small children to play with the chair.
- Not paying attention to these warnings could result in injuries.

CARE AND MAINTENANCE

- To clean the chair it is recommended to use a soft cloth lightly damped in a solution of smooth soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean any part of the chair.
- Before applying a cleaning agent, test on a small hidden area of the chair, like underneath the seat.
- Do not expose the product to direct sunlight or to extreme environmental conditions.
- Every 4 months, inspect the chair completely and make sure that all screws are tighten.

TECHNI SPORT WARRANTY
Gaming Chair: 2-YEAR WARRANTY
Gaming Desk: 5-YEAR WARRANTY
Gaming Chair Metal Frame: LIFETIME WARRANTY

RTA Products, LLC has warranted the Techni Sport products to the original purchaser who acquired a new product from RTA Products or its authorized re-sellers of the product against defects in material or workmanship.

This warranty is expressly limited to the repair or replacement (at its option) of defective product components or materials as a result of a defect in materials or workmanship. This warranty is limited to merchandise purchased in the Continental United States. No assembly labor is included. The word "defects" as used in this warranty, is defined as imperfections that impair the utility of the product.

This warranty applies under conditions of normal use, but does not apply to defects that result from intentional damage, wear & tear, negligence, unreasonable use or exposure.

Liability for consequential damages is excluded to the extent exclusion is permitted by law. This warranty gives you specific legal rights, and you may have other rights that vary from State to State.

RTA Products does not warrant: a) natural variations in character marks b) changes in surface finishes due to aging or exposure to light c) marks, scars, or wrinkles occurring naturally in leather d) failure resulting from normal wear and tear e) the matching of colors, grains, or textures of natural materials f) the colorfastness or the matching of textiles, including an exact match to cuttings or to swatch cards g) damage, marking, or staining of veneer surfaces due to contact with rubber or similar compounds, damage from sharp objects or imprinting from writing instruments, or prolonged exposure to direct sunlight h) we do not warrant products that are exposed to extreme environmental conditions or that have been subject to improper storage.

RTA Products shall not be liable for loss of time, inconvenience, commercial loss, or incidental or consequential damages.

Any modification to the original product voids the warranty. We do not warrant the performance of the product when used in combination with other than original products.

This product has been designed for and is intended for office, home-office and gaming use only. This warranty is Original Purchaser's sole remedy for product defects, and this warranty does not extend to any product, or damage to any product, caused by or attributed to abuse or misuse, products used for commercial or rental purposes, use modifications of, or attachments to the product, and products or parts not used, maintained, or extended here under is in lieu of any and all other warranties, express or implied, including without limitations any implied warranty or merchant ability or of fitness for a particular purpose.

Report any defects to RTA Products, LLC together with your sales receipt or other proof of purchase. If the chair is defective within the terms of the warranty, RTA Products, LLC will furnish a replacement chair (at its option) at no cost of equal or similar value and design.

RTA Products will advise you of the procedure to follow in making warranty claims. The following are the procedures for warranty claims:

a) Call us Monday – Friday, from 9am-5pm (Eastern Time) at (866) 782-5520 to explain the defect and give your name, address and phone number. Please have ready the model number of our product, date and place of purchase. You can also write to us by e-mail to warranty@rtaproducts.com and include the same information.

b) If we determine that replacement will remedy the situation, and in order to determine the extent or the cause of the defect, purchaser will need to send the part in question at purchaser's expense. Once we receive the part, we will examine it and determine whether the claim is valid (or not), and then proceed to send the replacement. We will ship the replacement at our expense.

SUPPORT OPTIONS:

- **Assembly questions**
 - **Damage issues**
 - **Replacement parts**
-

GO TO: [TECHNISPORTUSA.COM](https://www.technisportusa.com)



CLICK ON SUPPORT TAB



Scan QR Code to order replacement parts

CONTACT US BY EMAIL:

SUPPORT@TECHNISPORTUSA.COM