

This comprehensive care guide for fireclay sinks is designed to help you maintain its beauty and durability while ensuring a pristine appearance for years to come.



General Care:

- Clean the sink daily using a sponge or a soft cloth with warm water and mild dish soap.
- Use a sponge and scrub in small, circular movements.
- Thoroughly rinse the sink with warm water.
- Gently dry the sink with a soft microfiber cloth after use and cleaning.



Water Spots & Limescale:

- Apply a 50/50 water-vinegar mix to the sink surface.
- Use a sponge and scrub in small, circular motions.
- Rinse and dry the sink with a soft or microfiber cloth.



Deep Cleaning & Stains:

- Apply a 50/50 water-bleach mixture to the stained area.
- Scrub with a sponge in small circular movements.
- Thoroughly rinse the sink.
- Dry the sink with a soft or microfiber cloth.



Scuff Marks:

- Use a Mr. Clean Magic Eraser or a Cramer stain eraser and follow the instructions on the product.
- Thoroughly rinse the sink.
- Dry the sink with a soft or microfiber cloth.



Chips and Scratches:

- Ensure the sink is clean and dry.
- Use the proper Fixture-Fix product for your sink. Follow the product's instructions.

✓ DO's

Allow hot pans to cool before placing them in the sink.

Always run cold water when pouring boiling water into the sink.

Always rinse and dry the sink after use.

✗ DON'Ts

Never use abrasive or caustic cleaning agents containing ammonia or alkalis to clean the sink's surface.

Never use abrasive cleaning products such as steel wool or scouring pads.

Never leave water, food or cleaners sitting in the bowl for extended periods of time.



Recommended Products

- 50/50 Water-bleach solution
- 50/50 Water-vinegar solution
- Cramer Stain Eraser
- Fixture-Fix
- Mr. Clean Eraser

SCAN TO REGISTER



www.ruvati.com/register

For more information visit
www.ruvati.com/care



Address: 2705 Meister Pl, Round Rock, TX 78664

USA Phone: 1.855.478.8284

Email: support@ruvati.com