



USE AND CARE GUIDE

ST. CHARLES RECTANGULAR DINING TABLE



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents	2
Important Safety Instructions	2
Save These Instructions	2
Read All Instructions Before Use	2
Warranty	3
What is Covered	3
What is Not Covered	3

Pre-Assembly Planning Assembly	
Hardware Included	
Package Contents	4
Assembly	5
Care and Cleaning	

Important Safety Instructions

SAVE THESE INSTRUCTIONS

WARNING: This table was as made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this product when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean, or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the table while it is occupied. Failure to obey this caution could result in injury.

WARNING: Do not place heavy objects on the table.



WARNING: When not in use, secure the product in a cool and covered location.



WARNING: This table unit is heavy, and may require two adults for safe assembly.



CAUTION: Do not locate the product near any heat source.

Warranty

5 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-800-986-3460 or visit www.homedepot.com/homedecorators.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED

Ø

NOTE: Hardware not shown to actual size.


Маллин — вв

∎D - CC

Part	Description	Quantity
AA	M6x15 Combination Bolt	4+1
BB	M6x30 Combination Bolt	8+1
CC	Hex Wrench	1

Pre-Assembly (continued)

PACKAGE CONTENTS



Part	Description	Quantity
A	Table Top	1
В	Leg Connector	1
C	Table Leg	2


Assembly



Attaching the Table Legs to the Table Top

- $\hfill\square$ \hfill Place the table top (A) upside down on a soft surface.
- □ Attach the table legs (C) to the table top (A) using M6x30 combination bolts (BB).
- Do not tighten all bolts at this step.


NOTE: Loosely tighten all the bolts using hex wrench (CC).



Assembly (continued)

2 Connecting the Leg Connector to the Table Legs

- □ Connect the leg connector (B) to the table legs (C) using M6x15 combination bolts (AA).
- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (CC).



Assembly (continued)



Checking the Table

- $\hfill\square$ Turn the table right side up.
- $\hfill\square$ Ensure all connections are secure before use.



Care and Cleaning

- □ For best results, clean the table with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- □ Store the table in a dry, sheltered place when not in use.
- □ Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS


Retain this manual for future use.

For certification use only		
Factory ID# FTM71061		



USE AND CARE GUIDE

ST. CHARLES 6PK DINING CHAIR



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents.	2
Important Safety Instructions	2
Save These Instructions	2
Read All Instructions before Use	2
Warranty	3
What is covered	3
What is not covered	3

Pre-Assembly 3
Planning Assembly 3 Hardware Included 4
Swivel Chair Package Contents4
Stationary Chair Package Contents5
Swivel Chair Assembly
Stationary Chair Assembly 14
Care and Cleaning 19

Important Safety Instructions

SAVE THESE INSTRUCTIONS

WARNING: This set was as made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this product when any formidable / severe weather is approaching.

WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean, or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the set while it is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the stationary chair as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for each chair is 250 lb (113.39 kg).



WARNING: This set is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the set.

5 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-800-986-3460 or visit HOMEDEPOT.COM/HOMEDECORATORS.

Pre-assembly

PLANNING ASSEMBLY

Read all instructions before assembly. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)

HARDWARE INCLUDED




	— AA 🕅 🗰 — BB		DD)0
Part	Description	Quantity		
AA	M6x30 Combination Bolt	24+1		
BB	M8x20 Combination Bolt	8+1		
CC	M6x20 Bolt	12+1		
DD	Hex Wrench	1		
EE	Wrench	1		

_____p


— EE


SWIVEL CHAIR PACKAGE CONTENTS

Part	Description	Quantity
Α	Support Bar	2
В	Backrest	2
C	Swivel Chair Left Arm	2
D	Swivel Chair Right Arm	2
E	Swivel Chair Seat	2
F	Support Tube	2
G	Swivel Base	2
Н	Back Cushion	2
I	Seat Cushion	2



STATIONARY CHAIR PACKAGE CONTENTS






Part	Description	Quantity
A	Support Bar	4
В	Backrest	4
Н	Back Cushion	4
I	Seat Cushion	4
J	Stationary Chair Left Arm	4
K	Stationary Chair Right Arm	4
L	Stationary Chair Seat	4

Swivel Chair Assembly

Inserting the Support Bar, Backrest and Swivel Chair Seat into the Swivel Chair Left Arm


- □ Place the swivel chair left arm (C) on a soft surface.
- □ Insert the support bar (A), backrest (B) and swivel chair seat (E) into the swivel chair left arm (C).




2

Attaching the Swivel Chair Seat to the Swivel Chair Left Arm


- □ Attach the swivel chair seat (E) to the swivel chair left arm (C) using M6x30 combination bolts (AA).
- □ Do not tighten all bolts at this step.





3 Inserting the Swivel Chair Right Arm into the Support Bar, Backrest and Swivel Chair Seat

□ Insert the swivel chair right arm (D) into the support bar (A), backrest (B) and swivel chair seat (E).






Attaching the Swivel Chair Right Arm to the Swivel Chair Seat

- □ Attach the swivel chair right arm (D) to the swivel chair seat (E) using M6x30 combination bolts (AA).
- □ Do not tighten all bolts at this step.




NOTE: Loosely tighten all the bolts using hex wrench (DD).






Connecting the Support Bar to the Arms

- □ Turn the swivel chair right side up.
- □ Connect the support bar (A) to the swivel chair left arm (C) and swivel chair right arm (D) using M6x20 bolts (CC).
- $\hfill\square$ Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (DD).




Attaching the Support Tube to the Swivel Chair Seat

- □ Place the swivel chair upside down on a soft surface.
- □ Attach the support tube (F) to the swivel chair seat (E) using M8x20 combination bolts (BB).
- □ Fully tighten all the bolts using the wrench (EE).



Inserting the Support Tube into the Swivel Base


□ Insert the support tube (F) into the swivel base (G).





Placing the Seat Cushion and Back Cushion on the Swivel Chair


- □ Place the seat cushion (I) and back cushion (H) on the swivel chair.
- □ Ensure all conections are secure before use.



Stationary Chair Assembly

Inserting the Support Bar, Backrest and Stationary Chair Seat into the Stationary Chair Left Arm


- □ Place the stationary chair left arm (J) on a soft surface.
- □ Insert the support bar (A), backrest (B) and stationary chair seat (L) into the stationary chair left arm (J).




2

Attaching the Stationary Chair Seat to the Stationary Chair Left Arm


- □ Attach the stationary chair seat (L) to the stationary chair left arm (J) using M6x30 combination bolts (AA).
- □ Do not tighten all bolts at this step.





3 Inserting the Stationary Chair Right Arm into the Support Bar, Backrest and Stationary Chair Seat

□ Insert the stationary chair right arm (K) to the support bar (A), backrest (B) and stationary chair seat (L).






Attaching the Stationary Chair Right Arm to the Stationary Chair Seat

- □ Attach the stationary chair right arm (K) to the stationary chair seat (L) using M6x30 combination bolts (AA).
- □ Do not tighten all bolts at this step.




NOTE: Loosely tighten all the bolts using hex wrench (DD).





Connecting the Support Bar to the Arms


- □ Turn the stationary chair right side up.
- □ Connect the support bar (A) to the stationary chair left arm (J) and stationary chair right arm (K) using M6x20 bolts (CC).
- □ Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (DD).



6

Placing the Seat Cushion and Back Cushion on the Stationary Chair

- □ Place the seat cushion (I) and back cushion (H) on the stationary chair.
- □ Ensure all connections are secure before use.



Care and Cleaning

- □ For best results, clean the chair with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- $\hfill\square$ Do not clean with abrasive materials, bleach, or solvents.
- $\hfill\square$ Store the chair in a dry, sheltered place when not in use.
- □ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.

For certification use only Factory Swivel Chair ID# FZM71027S Factory Stationary Chair ID# FZM71027