
Replacement Parts List

Teapot 4 in. Centerset 2-Handle Low-Arc Bathroom Faucet in Polished Brass

MODEL	SKU #	FINISH
67092W-6A02	102823	Polished Brass



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Index (C)	RP1000202	206128291	
2	Screw	RP50005		
3	Handle seat	RP1702702		
4	Retainer	RP1313602	206131723	
5	Handle (C)	RP13005		
6	Cap & Bolt	RP1300602		
7	Inverter	RP64044	206671349	
8	Bonnet nut	RP70193	206671342	
9	Washer	RP64123		

Part	Description	Part #	Internet SKU #	Store SKU #
10	Cartridge (H)	RP20067	301158139	
11	Cartridge (C)	RP20068	301158129	
12	Gasket	RP80182		
13	Mounting nut	RP56001	203193994	579276
14	Index (H)	RP1000102	206128283	
15	Handle (H)	RP13004	206131852	
16	Aerator	RP3021002		
17	ClickInstall™ drain assembly	RP4022802		
18	Lift rod	RP4020402		