

FAQs

- **How do I figure out the size of my room?**
- When you're shopping for an air purifier to improve the air quality in a room, it's critical to ensure that you select a model that has the capacity to handle the area. That begins with determining the size of the room. To calculate the square footage (ft²) of your room, simply measure its length and width and then multiply the two numbers together.

Examples;

$$12\text{ft} \times 10\text{ft} = 120\text{ft}^2$$

$$16\text{ft} \times 20\text{ft} = 320\text{ft}^2$$

- **Which model of air purifier do I need for my room size?**
- Once you know the square footage of the room, you're ready to select an appropriately sized air purifier.
 - Here are the maximum effective square footage capacities of our three available air purifier models;
 - Bosch Air 2000 - **810ft² per 60 minutes**
 - Bosch Air 4000 – **1,345ft² per 60 minutes**
 - Bosch Air 6000 – **1,935ft² per 60 minutes**
- **What types of pollutants does each air purifier model filter out?**
 - Bosch Air 2000 - 3 in 1 filter (pre-filter/HEPA/active carbon) that reduces pollen, allergens, dust, viruses, odors, VOCs, and pet hair.
 - Bosch Air 4000 - 3 in 1 filter (pre-filter/HEPA/active carbon) that reduces pollen, allergens, dust, viruses, odors, VOCs, and pet hair.
 - Bosch Air 6000 - 4 in 1 filter (pre-filter/HEPA/active carbon) that reduces pollen, allergens, dust, viruses, odors, VOCs, pet hair, and includes an antibacterial chemical treatment to prevent the build-up of bacteria on the filter.
- **What are the physical dimensions of each of the air purifier models?**
 - The physical dimensions of the air purifier models are;
 - Bosch Air 2000 - **15.28in (H) x 9.25in (Diameter)**
 - Bosch Air 4000 - **19.69in (H) x 11.46in (Diameter)**
 - Bosch Air 6000 - **29.37in (H) x 12.76in (Diameter)**

Do I need a contractor to install the air purifier?

Not at all! Just plug the air purifier into the nearest grounded 120v outlet, press the power button to turn it on, and the unit will start in Auto mode and begin cleaning the air.

What are the various modes used for?

All three of the air purifier models have three modes of operation that you can choose from;

- **Auto** - The air purifier will continuously monitor the air quality in the room and adjust the fan speed automatically as needed.
- **Manual** - You can choose a fan speed yourself and the air purifier will not automatically adjust it.
- **Sleep** - This will dim the air purifier's lighting and slow the fan down to its quietest speed.

What is the noise level of each of the air purifier models?

With the air purifier running at full speed, the maximum noise levels are;

- Bosch Air 2000 - Up to 49db
- Bosch Air 4000 - Up to 49db
- Bosch Air 6000 - Up to 55db

I have the air purifier in my bedroom, but the brightness of the status light ring is bothering me. Can I turn it off?

If you would like to dim the brightness of the lighting, you can put the air purifier into Sleep Mode by using the controls located on top of the unit.

Alternatively, you can long press the quiet mode button to turn off the light ring, without going into quiet mode. This also slows the fan RPM down to its lowest possible speed to reduce the noise level too.

How often does the filter need to be replaced?

The practical lifetime of the replaceable filter will depend on;

- How long the air purifier has been running.
- The amount of airborne pollutants in the room.
- How often the user maintains the filter by cleaning it.