



Parts List for BEMW482ES Type 1

Item Number	Part Number	Description	Qty Required
2	N546801	BASE	1
3	N525936	HANDLE	1
4	N549267	HOUSING	1
5	N549271	HANDLE	1
6	N549272	HANDLE	1
7	N529144	TRIGGER	1
8	N529145	TRIGGER	1
9	N529479	LINK	2
10	N529480	BUTTON	1
11	90562582	SWITCH	1
12	N549280	SPRING	1
13	N568719	SPRING	1
14	90601713	CORDSET	1
16	N549264	CABLE	1
17	N528696	TUBE	1
20	N562493	GRASS BAG	1
23	90603928	HANDLE	1
24	90601398	GRASSFLAP	1
25	N564205	SPRING	1
26	90574276	FASTENER	4
27	N525968	WHEEL	2
28	N525967	WHEEL	2
29	90561676-01	PLASTIC COVER	1
30	90561653	PLASTIC COVER	1
31	90561677	PLASTIC COVER	1
32	90567592-02	PLASTIC COVER	1
33	90562116	CONNECTING ROD	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for BEMW482ES Type 1

Item Number	Part Number	Description	Qty Required
35	90571019-01	LOWER HOOK	1
36	90589823	SCREW	1
37	747329	SCREW	18
39	90579431	RETAINING RING	2
40	90579432	RETAINING RING	2
41	90565594	HEIGHT ADJUST COVER	1
42	N546809	COVER	1
43	90561599	AXLE	1
44	90561600	AXLE	1
45	N548691	NUT	2
46	90569681	EXTENSION SPRING	1
47	N520728	BLADE	1
48	90603745	HEX HEAD BOLT	1
49	90568882	SLIDER	1
51	330019-13	SCREW,PLASTITE	5
52	90573272	FLAT WASHER	4
53	N547167	WEIGHT	1
54	N563381	CORD CLAMP	2
56	90606208	HEAT SHRINK SLEEVE	2
57	90512672	DANGER LABEL	1
58	N533248	RATING LABEL	1
59	N524890	BLADE CARRIER	1
60	90600246	FLAP	1
61	90600213	SHAFT	1
62	241658-03	RING,PUSH	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.