

WESTBRASS

Fine Decorative Plumbing Since 1935

Bathroom Faucet


Models: WAS00X-07, WAS00X-12A, WAS00X-26

ASME A112.18.1 / CSA B125.1

Llave Para Lavamanos

Modelos: WAS00X-07, WAS00X-12A, WAS00X-26

YOU MAY NEED: USTED PUEDE NECESITAR:



Water Supply Connectors not provided. Choose connectors with 1/2" iron pipe outlet connections.


El Tubo De Abasto No Es Proveído. Seleccione su tubo de abasto con conector de 12,7mm para tubo de hierro.




Important: Use Teflon Tape on all threaded connections.
Importante: Use cinta para plomero todas las conexiones roscadas.




Silicone Sealant: Use silicone sealant under base of faucet.
Sellador de silicón: Si el lavamanos está desnivelado use sellador de silicón debajo de la base del borde.



Wrenches: For faucet removal and installation.
Llaves: Para quitar y instalación de lavamanos.



Complete Pop-up Assembly Ensamble Completo del Desague Automatico



1. Shut off Water Supply:

Remove old faucet. Place gasket on bottom of faucet. Use silicone seal between gasket and sink surface.

2. Secure faucet to sink:

Using locknuts provided. Do not over tighten. Clean-up excess silicone.

3. Install water supplies (Not included):




To bottom of faucet. Use connectors to fit on 1/2" iron pipe.

4. Install pop-up body using silicone sealant:

Under the flange, between flange and sink. Replace black gasket (flat side down) on nut and hand tighten nut. Place drain with pivot entry facing towards faucet. Clean-up excess silicone.

5. Install pop-up drain assembly:

Using removable or non-removable pop-up installation.



1. Cierre el Suministro de Agua:

Quite la llave vieja. Coloque el empaque en la parte inferior de la llave. Asegúrese de aplicar un sellador con base de silicón entre el empaque de la llave y el lavamanos.

2. Fije la llave al fregadero:

Con las contratuercas proporcionadas. Apriete Solo Con La mano.

3. Conecte al tubo de abasto.


Nota: El Tubo De Abasto No es proveído. Seleccione su tubo de abasto con conector de 12,7mm para tubo de hierro.

4. Instale el cuerpo del desagüe con sellador con base de silicón:

Debajo de la brida. Reemplace el empaque negro (el lado plano hacia abajo) y la tuerca. Apriete a mano la tuerca. El hoyo del pivote debe de estar viendo la parte trazera del fregadero.

5. Instale el ensamble del desagüe automático.
Instalacion Separable o Instalacion No Separable.

6. Important: After installation is complete, remove aerator by turning counter-clockwise, turn handles on to full on mixed position. Turn on water supplies and check for leaks. Let lines flush for one minute to eliminate debris and flush valves, without moving handles. After flushing, shut off water at faucet and replace aerator.



Importante: Después que la instalación está completa, quite el aireador, gire la manijas a la posición de temperatura mixta y ábralo al máximo. Abra las líneas de suministro e inspeccione en caso de fugas, dejando que fluya el agua un minuto entero sin mover la manijas de la llave. Esto hará salir toda partícula o basura de la línea, la cual podría causar daños a componentes internos de la llave o causar fugas. Después de hacer esto, cierre la llave y reemplace el aireador.

CARE INSTRUCTIONS

Care Instructions

Care should be given to the cleaning of this product.

To Clean

Wipe gently with a damp cloth.

Blot dry with a soft towel.

Maintenance

Shut Off Water Supply before replacing Cartridge.

If faucet leaks from spout:

Replace Ceramic Cartridge. URP33447 and URP33448

If Faucet exhibits low flow:

Remove and Clean Aerator

Install cartridges correctly for proper handle rotation:

For Lever handles, the stops must point to the right when installed.

Instrucciones Sobre el Cuidado

Se debe tener cuidado con la limpieza de este producto.

Para limpiar:

Frote con un Paño húmedo.

Séquela con una toalla suave.

Mantenimiento

Cierre Los Suministros De Agua.

Si la llave tiene fugas en la salida:

Reemplace Cartucho de Cerámica, Equipo para Reparación URP33447 y URP33448

Si la llave muestra un flujo muy bajo:

Quite y limpie el aireador

Instale los cartuchos correctamente para una giración correcta de la manija:

Para manijas de palanca, los topes deben señalarse a la derecha cuando son instalados.

WARRANTY

Drain and Strainer Finishes:

All sink and tub/shower drains, strainers and other trims have a 1 year warranty in the following finishes:

(01) PVD Polished Brass

(26) Polished Chrome

(07) Satin Nickel

(12) Oil Rubbed Bronze

(50) Powder Coated W

(62) Powder Coated Flat Black

Other Westbrass finishes, including living finishes and other electroplated finishes carry no warranty.

Functional Warranty:

The functionality of all products is warranted for a period of one year. Ceramic disc valves on any water delivery merchandise are warranted for one year. Warranties are guaranteed to the original purchaser only. Product problems attributable to abuse, misuse, improper installation, hard water, neglected maintenance or accidental damage are not covered by this warranty. Modifying the product in any way voids the warranty. The use of plumber's putty on our products also voids the warranty. Silicone

sealing compounds should be used instead. No repairs or replacements will be made under such circumstances except at customer's expense. Liability under warranties expressed or implied is limited to repair or replacement of defective goods only. In no event will Westbrass be liable for incidental or consequential damages (such as labor charges). This warranty does not cover labor charges, whether based on breach of express or implied warranty, breach of contract, negligence or any other legal theory.