

## Important Safety Information:

### WARNING

- This product is for outdoor use only, under 80 psi.
- Do not use indoors.
- Avoid stretching the hose when empty. It can snap back and cause injury.
- Keep the hose away from children and pets to prevent strangulation hazards.
- Do not use in commercial, hot water, or high-pressure applications.
- Always supervise the product when in use.
- Directing high-pressure spray at people, pets, or fragile objects is dangerous.
- Store indoors and away from extreme weather and sunlight.

### Drinking Water Advisory :

- Pocket Hose® hose is lead-free and designed with drinking water safety in mind.
- For safety, it's best to avoid drinking from any garden hose, including ours.
- Flush the hose by letting water run to clear stagnant water before use.
- Regular cleaning of the hose, especially connectors, is recommended.
- Store in cool, shaded areas and inspect regularly for damage.
- The hose is intended for gardening and agricultural-related tasks.

### Pocket Hose® History:

The history of the garden hose industry is a testament to the human spirit of innovation and the relentless pursuit of convenience. Primitive channels to carry water evolved into the heavy, unwieldy rubber hoses of the 19th century. Yet, this indispensable tool was often a source of frustration for homeowners and gardeners, due to its bulkiness and difficulty to manage.

This all changed in 2012 when the Pocket Hose® emerged, a revolution in simplicity, portability, and efficiency that forever transformed the garden hose industry. With over a decade of constant innovation, we proudly bring you our advanced Pocket Hose® Copper Bullet™. Enjoy.

Questions? Visit [PocketHose.com](http://PocketHose.com) for more information.



Telebrands Corp., 79 Two Bridges Road, Fairfield, NJ 07004

Patented Worldwide  
visit [PocketHosePatents.com](http://PocketHosePatents.com)

©2023 DaVinci CSJ, LLC

Designed and distributed in USA by Telebrands Corp. d/b/a Bulbhead  
Unauthorized reproduction, distribution, or transmission of this manual, in part or in whole, is prohibited without prior written consent from Telebrands Corp.

Made in China.

Product may vary from images shown.

# POCKET Hose®

## Copper Bullet™

### Essential User Guide



Easy  
Thumb  
Control

**Richard Karn**  
Home Improvement  
Expert

Read all instructions and warnings carefully before using this product. Injury and/or household damage can result from improper use. Save these instructions.

#### LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. Telebrands Corp. shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

Welcome to the Pocket Hose® Family! We're thrilled to introduce you to the revolutionary Copper Bullet™. This guide will help you maximize the potential of your new garden tool.

### Instructions For Use:

- 1. Unpacking:** Gently remove your Pocket Hose® Copper Bullet™ from the package and lay it flat to unravel.
- 2. Connection:** Attach the Pocket Hose® connector to your home's outdoor water supply by turning it clockwise until securely attached. **Figure 1.**
- 3. Operation:**
  - a. Make sure the Shutoff Valve is in the closed position. **Figure 2.**
  - b. Turn on your home's water tap.
  - c. Watch as the Pocket Hose® expands to its full size.
  - d. To start the water flow, gently turn the Shutoff Valve a quarter turn clockwise. **Figure 3.**




Figure 1




Figure 2





Figure 3

For optimal performance, make sure the hose is fully extended before using it to prevent any water flow restrictions.

### Using Thumb Drive™ 10 Pattern Sprayer:

- 1. Attachment Instructions:**
  - a. Turn the Shutoff Valve to the closed position. **Figure 2.**
  - b. Attach the Thumb Drive™ sprayer to the hose end, ensuring the rubber washer is in place.



**Note:** Your sprayer comes with 3 extra rubber washers. Only use in case of leaking at spigot end of hose.

### 2. Sprayer Use:

- a. To start spraying, pull the thumb control down. **Figure 4.**
- b. To stop spraying, push the thumb drive up. **Figure 5.**
- c. Change the spray pattern by rotating the Spray Head until it clicks into your desired setting. **Figures 6,7.**




Figure 4




Figure 5




Figure 6




Figure 7

### Advanced Usage:

Explore the various spray patterns to find the perfect one for every gardening task, from a gentle mist for delicate plants to a strong jet.

### Storage:

- After use, turn off the water supply and drain the hose by leaving the thumb control in the down (spray) position. The hose will shrink back to its original size.
- Always store your Pocket Hose® indoors to extend its lifespan.

Instructions continued ➡