

CONGRATULATIONS!

Thanks for your purchase of Arctic Air® Pocket!
Simply fill the Arctic Air® Pocket with water & enjoy cool air... anywhere! This powerful handheld cooler uses dual atomizers combined with a powerful fan to deliver a cool refreshing breeze. Includes USB-C rechargeable batteries, & a kickstand for hands free use. This Compact & Portable Cooler will keep you refreshed & comfortable for hours.

CUSTOMER SUPPORT

🌐 www.PocketChillFAQ.com
☎ 1-877-305-8980
✉ PocketChill@rephelpdesk.com

WHAT'S INCLUDED:


Charging Cable



HOW TO USE:


**You can use Arctic Air® Pocket on-the-go,
or using the built-in stand.**

1. To fill with water, open the water fill door on the back of the unit, and carefully pour in cold water. We recommend using a pitcher (or anything with a spout) to avoid spilling, instead of filling under a faucet. Close door when full.




2. To turn your Arctic Air® Pocket on, press the power button on the front.

NOTE: Fan speed will default to high – press again to change the Medium, and again to change to Low.




3. When fan is on, cooling jets will gently spray water from front of unit to enhance cooling.

IMPORTANT: Cooling Jets may take up to 1 minute to begin fully working while unit is priming.




HOW TO USE (cont.):


4. To set moodlight color, press the  button on the side.



5. If using at a desk or table, simply flip kickstand out and let Arctic Air® Pocket rest on stand.



6. When done, press the power button until unit turns off. Empty out remaining water, and store in a cool, dry location until next use.




CHARGING:


Arctic Air® Pocket comes partially charged –
For Best Results, fully-charge battery before first use.

NOTE: When fully charged, you can expect
runtime of 12 hours depending on fan speed.


1. Using included USB cable,
plug small end into charging
port located on side of unit.



2. Plug large end of USB cable
into a USB-Power adapter,
laptop, or other device
(not included).



3. Charge indicator light will
remain red to indicate the
unit is charging. When the
indicator light remains solid
green, Arctic Air® Pocket
is fully charged.



WARNINGS:

- DO NOT submerge Arctic Air® Pocket in any liquid.
- DO NOT expose Arctic Air® Pocket to wet or damp area.
Use only in a dry locations.
- DO NOT attempt to remove or replace the included battery.
- DO NOT place near open flames or fire sources.
- DO NOT use solvents or alcohols for cleaning Arctic Air® Pocket.
- Only use the original power cord supplied in package.
- DO NOT allow any foreign objects inside Arctic Air® Pocket.
- Arctic Air® Pocket is intended for household use.
- The manufacturer does not bear any responsibility for any
damage from failure to comply with this product guide.

ONTEL® ASSUMES NO RESPONSIBILITY FOR ANY INCIDENTAL
OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF
THE PRODUCT. IN PURCHASING AND USING THIS PRODUCT, YOU
ASSUME ALL RESPONSIBILITY FOR CLEANING THE PRODUCT AND
MONITORING THE PRODUCT FOR MOLD. ADDITIONALLY, ONTEL®
SPECIFICALLY DISCLAIMS ALL EXPRESSED WARRANTIES NOT
OTHERWISE SET FORTH HEREIN AND ANY IMPLIED WARRANTIES
OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.
THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE
DESCRIPTION OF THE FACE HEREOF.

Distributed by
OnTel
PRODUCTS CORPORATION

Made In China
Patents Pending.

AAPC-IM-02-0922-200

©2022 Ontel Products Corp.
Fairfield, NJ 07004
All Rights Reserved.

Model: 21076
5V DC, 1A
3.7V 2000mah

ARCTIC
AIR® Pocket
Evaporative Air Cooler



Product Guide
SAVE THESE INSTRUCTIONS