



TM

HANGTAG REMINDER




For More Troubleshooting
Information, Scan QR Code

N1

Section Out?

Ensure pole is fully connected




No Lights Working?

Check For Loose Connection




Not Full?

Spread Branches




Tree Topper?



Branch Hanging Low?

Bend up



Lights Cycle Through Functions?

This tree is preset to Demo Mode.

To deactivate:

Press another light function button to switch to a different function.

To activate:

Press the "Demo" button once.

1. Warm White-Multi Fast Fading
2. Warm White Fast Fading
3. Warm White-Multi Alternating
4. Warm White Steady
5. Warm White-Multi Slow Fading
6. Multi Steady
7. Multi Fast Fading
8. Demo



Remote Control

Other Issue? Call 1-855-HDHoliday (1-855-434-6543)