


# REPLACEMENT PARTS - MODEL TB400

## 2-CYCLE BLOWER

PPN 41AR25BL766




Item	Part No.	Description
1	753-08523	Handle Assembly (includes 2-7)
2	731-11027-1	Handle (LH)
3	753-05007	Trigger Spring
4	791-182405	On/Off Switch
5	731-10776A-1	Handle (RH)
6	731-09987-10	Throttle Trigger
7	710-04194	Screw
8	841-014061S	Impeller Housing Assembly (RH)
9	710-06341	Screw
10	753-08491	Impeller Assembly
11	736-05080	Washer
12	736-04110A	Lock Washer

Item	Part No.	Description
13	712-04137	Nut
14	753-08533	Impeller Housing Assembly (LH) (includes 7)
15	731-10598	Upper Blower Tube
16	731-10604	Blower Nozzle
17	753-08500	Fuel Tank Assembly
18	791-182366	U-Shaped Nut
19	791-181930	Screw
20	753-08494	Intake Cover (includes 7)
21	750-06367	Shaft Spacer
22	753-08496	Engine Adapter (includes 9)
23	753-08510	Engine Cover Housing (includes 7)

# REPLACEMENT PARTS - MODEL TB400

## 2-CYCLE BLOWER

PPN 41AR25BL766



Item	Part No.	Description	Item	Part No.	Description
24	753-09204	Shortblock Assembly	33	746-05226	Throttle Cable
25	753-06847	Spark Plug	34	753-08490	Flywheel Assembly
26	753-06189	Insulator Assembly (includes 27)	35	753-08489	Module Assembly (includes 36)
27	753-06185	O-Ring	36	710-06301	Screw
28	753-06423	Carburetor	37	753-08488	Muffler Assembly (includes 38, 39 and 40)
29	721-04381	Carburetor Gasket	38	710-05077	Muffler Screws
30	753-08498	Air Cleaner Assembly (includes 31)	39	2592	Washers
31	791-181757	Air Cleaner Filter	40	721-04801	Muffler Gasket
32	725-06313	Lead Wire	41	721-04824	Shortblock Gasket