

Artificial Christmas Tree Assembly Instructions

Thank you for purchasing our Artificial Christmas Tree! Follow these simple steps to assemble and enjoy your festive centerpiece. These instructions apply to both pre-lit and unlit models with a weighted pot or base.

Step 1: Unpack and Prepare

Carefully remove all parts from the box. Check that you have all sections of the tree (base, middle, and top), along with the weighted pot or base. Straighten the branches slightly for easier assembly.

Step 2: Insert the Bottom Section

Place the weighted pot or base on a flat surface. Insert the bottom section of the tree securely into the base until it fits snugly. Ensure the tree is upright and stable.

Step 3: Add Remaining Sections

Connect the middle and top sections one at a time, aligning the poles and inserting them firmly. Adjust branches as needed for even spacing.

Step 4: Shape the Branches

Gently spread out each branch to create a full, natural look. Start from the bottom and work your way up. Bend the tips slightly upward for a lifelike appearance.

Step 5: Connect Lights (Pre-Lit Models Only)

If your tree is pre-lit, locate the light connectors between each section and plug them together. Once all connections are secure, plug the power cord into a wall outlet and test the lights.

Step 6: Decorating and Final Touches

After shaping and lighting, decorate your tree with ornaments, ribbons, and a tree topper of your choice. Step back occasionally to ensure even decoration placement.

Care & Storage Tips

- Avoid placing the tree near heat sources or open flames.
 - For unlit models, consider adding LED string lights for extra sparkle.
 - When the season ends, carefully remove decorations and disassemble sections.
 - Store the tree in a cool, dry place using the original box or a storage bag.
-