

Installation Steps

Step 3: Install Pop-up Adapter

1 | Lay out system and dig trench

2 | Connect EZ-Drain and place in trench

3 | **Install Pop-up Adapter**

4 | Backfill and replant



Install Pop-up Adapter

Using a corrugated pipe adapter, connect a drain pipe to one of the piped sections of EZ-Drain to create a discharge point. Connect the drain pipe to an elbow with a weep hole. The elbow should be installed with the weep hole on the horizontal side of the elbow. Slide the Pop-up Emitter onto the elbow. An additional length of pipe can be used between the elbow and Pop-Up Emitter to bring the Pop-up emitter to the surface. The Pop-Up Emitter fits on the bell or hub end of the pipe or a pipe coupler.

TIP: To avoid damaging your Pop-Up Emitter with your lawn mower, raise the cutting level of the blades or avoid passing the mower over the Pop-Up Emitter