


## Simplex Pushbutton Lock Instructions



**YOUR happiness matters to us here at V-Line Industries!**  
**Please call us for assistance before you consider returning your product.**  
**(805) 520 - 4987**

**To open** your push button lock with the factory setting (2&4 then 3):

**STEP 1.** Turn the knob to the left about  $\frac{1}{4}$  turn and release.

**STEP 2.** Push the #2 and the #4 buttons together,

**STEP 3.** Push the #3 button,

**STEP 4.** Turn the knob right (clockwise) a  $\frac{1}{4}$  turn to open.


**To lock:** Close the lid or door, turn the knob left (counter clockwise) a  $\frac{1}{4}$  turn or less, until it stops.

**Important:** Always turn the knob to the left before attempting to open lock. Please note, the knob has a clutch feature, meaning, it will cycle a  $\frac{1}{4}$  turn, if, excessive force is used without the proper combination. **VERY IMPORTANT: DO NOT use the same number more than once.**

**DO NOT FORCE DOOR CLOSED:** If door does not close, open and check to see if contents are interfering with lock function.

**WARNING: The lock does not operate automatically: Close lid or door, turn knob left in order to lock the Security Case.**

**To change your combination:** You may easily change to a new combination using one, all five, or any one of five buttons. Simple two and three button combinations are easy to remember and still provide security. **Note: A combination can include any one of five buttons in any order.** Two or more unique buttons may be pushed at one time as part of a combination. Record your new combination and store it in a safe. place.



**STEP 1.** Open the door or lid with the factory code or existing combination. Turn the knob to the left and release with the door open.

**STEP 2.** Enter existing combination, but **DO NOT TURN KNOB.**

**STEP 3.** Locate and push the "**L**" Tab in and release.

**STEP 4.** Turn the knob about  $\frac{1}{4}$  turn left (counter clockwise).

**STEP 5.** Enter new combination (see above for details). **DO NOT use the same number more than once.**

**STEP 6.** Turn the knob to the right about  $\frac{1}{4}$  turn (clockwise).

**STEP 7.** Turn the knob about  $\frac{1}{4}$  turn left. Your new combination is now installed.

**STEP 8.** CHECK THE NEW COMBINATION SEVERAL TIMES WITH THE DOOR OPEN BEFORE LOCKING THE DOOR.

**Video Link:** <https://www.youtube.com/watch?v=L645vQ1iUhg>

### **WARNING:**

**NEVER STORE FIREARMS AND AMMUNITION TOGETHER THE SAFEST PROTECTION AGAINST ACCIDENTS INVOLVING CHILDREN UNDER THE AGE OF 18 IS TO STORE YOUR FIREARM UNLOADED AND LOCKED, WITH THE AMMUNITION STORED IN A SEPARATE, LOCKED CONTAINER.**