




# WHT36 TIMER

## WIRING INSTRUCTIONS FOR WHT36



**SHUT POWER OFF AT BREAKER TO AVOID ELECTRIC SHOCK!**

1. Connect black power source wire to WHT36.
2. Connect black wall switch wire to WHT36.
3. Connect white power source wire to white on motor.
4. Connect blue wall switch wire to black on motor.
5. Connect red wall switch wire to red on motor.  
(Ground from power source to ground screw on motor)



Quality you Can Trust Since 1886... from North America's Largest Roofing Manufacturer

*And Ventilation*