



BAMBOO ROMAN SHADE INSTRUCTIONS




PREPARATION

1 Check the Hardware




A Bamboo Roman Shade x 1



B Bracket
23"-52" = (2)
60"-72" = (3)



D Bracket Screw
23"-52" = (8)
60"-72" = (12)



C Cord Cleat x 1




E Anchor
23"-52" = (8)
60"-72" = (12)



F Cord Cleat Screw x 2

2 Gather other necessary tools



⚠ WARNING

The cords on this product present a potential strangulation hazard.



For child safety, consider cordless alternatives or products with inaccessible cords.



⚠ WARNING

This product contains accessible lift cords. Accessible lift cords on the front & back of Roll-Up Style shades can be pulled out to form a loop, which can **STRANGLE** a young child.




Children can climb furniture to access lift cords. Move cribs, playpens, and other furniture away from window coverings.

INSTALLATION


1 Prepare the Brackets

Place **bracket B** on the **shade A** by putting bolt through hole on top of **shade**. Secure and tighten the **bracket**.


Bracket can be mounted behind the **shade** or to the side of **shade**.



mounted behind the **shade**.




mounted to the side of the **shade**.




2 Measuring

Ensure brackets are level with a steel tape measure and a level.

With the **brackets B** attached to the **shade A**, hold the shade against the window where the **shade** will be mounted. Mark the position of **brackets** with a pencil. Make drill marks, then remove brackets from the shade.




Wall Mount




Ceiling Mount

3 Installing Brackets

Place **brackets B** at pencil marks. Predrill small holes for screws. Screw **brackets screws D** into place securely.




Wall Mount



Ceiling Mount


4 Tighten wing nuts to complete installation

Insert the **shade A** into the **brackets B** making sure the butterfly screws go through the **shade** slots.



5 SAFETY FIRST! Install Cord Cleat

Find a convenient place a couple inches out from the right hand side of the **shade** and about 1/4 of the way up from the bottom. Hold the **cord cleat C** up parallel with the window frame. Mark dots through the holes. Make pilot holes and put the **cord cleat** up with two small **cord cleat screws F**. Cord can be wound in figure eights around the cord cleat to hold **shade** at desire height.




Quick How-to-use Guide

Pull cord to the left to lower the shade and release.

Pull cord straight down to raise the shade.

Pull cord to the right to lock into place.

Cords hang separate for child safety reasons. All cords must be pulled simultaneously and slowly for the shade to go up and down evenly.



Chicology Ready-Made Blinds and Shades Warranty

Limited One Year Warranty from the Date of Purchase

What is Covered :

- All of our shades are warranted against manufacturer defects in materials or workmanship provided that you are the original purchaser of the product, and the product was installed according to our instructions.

What is Not Covered :

- Normal wear and tear.
- Consumer damages caused by accidents, alterations, abuse of the product, exposure to salt air, misuse, or damages from pets or insects.
- Damages resulting from removal and reinstallation in the same or any other window or application, or failure to follow instructions, such as measurement, installation, cleaning, and maintenance.
- Any products that, with the passage of time, has yellowing or cracking of plastic parts
- Wrong measurements are not covered by the warranty and are not refundable.

To report shipping damages :

If damage occurred during shipping, please email support@chicology.com immediately and report within 14 calendar days or else you may be denied for your damaged product.

Obligations to the consumer :

The obligations of Chicology are limited to the repair or replacements of parts or products found to be defective. Chicology will determine if the product is defective or not and may replace the product. If the product is found to have manufacture defects, we will repair or replace the product. Colors do vary from lot to lot, and may not match original product exactly. Discontinued items will be replaced with the most current product of the same price.

Your Rights under State law :

This limited warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Contacting us :

If you believe your shade has a manufacturing defect, email us at support@chicology.com