

WARNING

Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock or serious personal injury.

SAVE THESE INSTRUCTIONS

Follow Instructions For Your Saw

Be sure to follow all of the safety instructions for your saw. Wear eye protection and use all recommended protective equipment.
Unplug Your Saw Before Installing or Adjusting the *SKATEPLATE™*
Disconnect the plug from the power source before installing or making any adjustments to the *SKATEPLATE™*. These preventive safety measures reduce the risk of starting the saw accidentally. Remove all adjusting keys or wrenches before turning the saw on.

Secure the Work Place

Use clamps or other practical ways to secure and support the work piece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control. NEVER hold the piece being cut in your hands or across your leg. It is important to support the work properly to minimize body exposure, blade binding, or loss of control. Do not force the saw.

SKATEGUIDE-ZILLA™ Use and Care

Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect operation of the *SKATEPLATE™*. If damaged, replace or repair before using. Certain cleaning agents such as gasoline, carbon tetrachloride, ammonia, etc. may damage plastic parts. Never clamp or tie the lower guard into the open position. Circular saws are not designed or intended to be used as table saws.

KICKBACK

KICKBACK may occur with the *SKATEPLATE™*. NEVER place your hand behind the saw blade since KICKBACK could cause the saw to jump backwards over your hand. Keep your body positioned to either side of the saw blade, but not in line with the saw blade. Follow all of the instructions for your saw to prevent KICKBACK.

LIMITED WARRANTY OF
CIRCSAW TECHNOLOGIES LLC PRODUCTS

CircSaw Technologies LLC (“Seller”) warrants to the original purchaser only, that all *SKATEPLATE™*, *SKATEGUIDE™*, *SKATEGUIDE-ZILLA™* and *SKATEPLATE H20™* products will be free from defects in material or workmanship for a period of 90 days from date of purchase.

SELLER’S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, altered or repaired by persons other than Seller or its Factory Service Center. To make a claim under this Limited Warranty, you must (a) contact CircSaw Technologies LLC at www.skateplate.com to obtain a Warranty Return Authorization, and (b) return the complete product, shipping prepaid, to the CircSaw Technologies LLC Factory Service Center specified.

SELLER DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF “MERCHANTABILITY” AND “FITNESS” FOR A PARTICULAR PURPOSE, AFTER THE 90-DAY TERM OF THIS WARRANTY. SOME STATES IN THE U.S.A. AND SOME CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.


IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR INJURY OR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT. SOME STATES IN THE U.S.A. AND SOME CANADIAN PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE IN THE U.S.A, PROVINCE TO PROVINCE IN CANADA AND FROM COUNTRY TO COUNTRY.

THIS LIMITED WARRANTY APPLIES ONLY TO PRODUCTS SOLD WITHIN THE UNITED STATES OF AMERICA, CANADA AND THE COMMONWEALTH OF PUERTO RICO.

SKATEGUIDE-ZILLA™ Fits both versions of the *SKATEPLATE™* and is intended for wider cuts of up to 27 inches!


SKATEGUIDE-ZILLA™ Can be used as a Reverse Guide by mounting the roller body in the opposite direction as shown. Reverse the Roller Head and install the cap screw on the opposite side. Do not install the handle. Store the handle and shoulder bolt in a safe location.



ASSEMBLY
STEP 1

Assemble *SKATEGUIDE-ZILLA™* by inserting cap screw as indicated. Install handle with the provided shoulder bolt and tighten by hand.

If a more permanent installation is required, use appropriate thread-lock fluid.



SKATEGUIDE-ZILLA™ Hardware

(1) Handle



(1) Roller Head



(1) Extended Ruler



(1) Handle Shoulder Bolt



(1) Cap Screw



STEP 2

WHEN USING THE *SKATEGUIDE-ZILLA™*, SLIDE INTO THE LEFT OR RIGHT SIDE OPENING OF THE *SKATEPLATE™* AS NEEDED AND ENSURE THAT THE *SKATEGUIDE-ZILLA™* IS AT MINIMUM COMPLETELY INSERTED INTO THE OPPOSING OPENING. TIGHTEN LOCKING BOLT. MEASURE YOUR CUT AND TIGHTEN THE *SKATEPLATE™* LOCKING BOLT TO SECURE THE *SKATEGUIDE-ZILLA™* POSITIONING.



Your *SKATEGUIDE-ZILLA™* is now ready for use!

