

Bed Frame Furniture Maintenance Manual Product Care & Maintenance Guide

Thank you for choosing our bed frame. To ensure its long-lasting beauty and structural integrity, please follow the maintenance guidelines below.

1. General Care Place the bed frame on a flat, level surface to prevent unnecessary stress or warping. Avoid dragging or pushing the bed frame across the floor, as this can loosen joints and damage both the frame and flooring.

Do not exceed the recommended weight capacity, including the combined weight of the mattress, users, and any stored items.

2. Cleaning Instructions Wood/MDF/Plywood Surfaces:

Use a soft, dry or slightly damp cloth to remove dust. Avoid using harsh chemicals, abrasive cleaners, or alcohol-based products that may damage the finish. Metal Parts (if applicable): Wipe with a soft cloth dampened with mild soap and water. Dry immediately to prevent

rust or corrosion. Upholstered Headboards (if applicable):

Vacuum regularly using a brush attachment. For stains, use a fabric-safe upholstery cleaner following the product instructions.

3. Environmental Conditions Keep the bed frame away from direct sunlight, which may cause fading, warping, or discoloration. Avoid placing the bed near heaters, fireplaces, or humidifiers, as extreme temperatures and moisture may cause structural damage over time. Maintain indoor humidity between 40 – 60% to protect wood components from cracking or swelling.

4. Assembly & Hardware Checks Periodically check and tighten all screws, bolts, and joints to ensure stability. If you hear any creaking or notice movement, inspect and reinforce all connection points as needed.

Do not modify or drill into any part of the frame, as this will void the warranty.

5. Mattress & Slat Support Use a compatible mattress size to avoid pressure on side rails or slats. Ensure slats are evenly spaced and fully secured to prevent mattress sagging or frame imbalance.

For beds with center support legs or beams, ensure they maintain even floor contact at all times.

6. Storage and Moving If disassembling for storage or relocation, label hardware and pack parts securely to avoid loss or damage. Store in a cool, dry place away from direct exposure to moisture or heat.

Reassemble according to the original instructions to maintain structural safety.