
HOME ACCENTS Holiday™

Item #1013854048
1013854056
Model #25PG50003
25PG50002

USE AND CARE GUIDE

Fresh-Cut Tree Stand



THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this tree stand. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

HOME ACCENTS Holiday™

Contact the Customer Service Team at
1-855-HDHOLIDAY (1-855-434-6543) or visit **www.HomeDepot.com**.

Questions, problems, missing parts?
Before returning to the store,
call **[HOME ACCENTS HOLIDAY]** Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

Safety Information

1. Read and save these instructions.
2. Heed all warnings and follow all instructions.

⚠ **WARNING:** Do not hammer the bottom of stand.

⚠ **WARNING:** Do not drop the tree into the stand with force.

⚠ **WARNING:** Do not overtighten the bolts.

Care and Cleaning


Store in a cool dry place. If the stand becomes dirty, clear with a cloth. Wash with soapy water and dry.

Pre-Assembly

PLANNING ASSEMBLY

Compare all parts with the Package Contents list in this manual.
If any parts is missing or damaged, do not install this product.
Contact the Customer Service Team.

PACKAGE CONTENTS




Part	Description	Quantity
A	Stand	1
B	Square nuts	4
C	Eye bolts	4
D	End-Caps	4

Assembly


1 Installing the square nuts

☐ Insert the square nuts (B) into the stand (A).




2 Installing the eye bolts

☐ Thread the eye bolts (C) into the square nuts (B).



3 Attaching the End-Caps

☐ Thread the End-Caps (D) onto the ends of the eye bolts (C).




Assembly (Continued)

4 Installing your tree

☐ Insert the tree into the stand. The trunk must engage the spike in the bottom of the stand. Trim excess branches as needed. The weight of the tree will set the spike into the trunk.


☐ Do not hammer the button of the stand or drop the tree forcefully into the stand. For stability avoid tightening eye bolts into knots or protrusions on the trunk. Lift and rotate the tree as needed.



5 Securing your tree in place

☐ Tighten the eye bolts (C) until they just touch the trunk.

☐ Straighten the tree and then tighten the eye bolts (C) hand tight. Fill the stand with fresh water.



Warranty

For Warranty information, please contact the Customer Service Team at 1-855-HDHOLIDAY (1-855-434-6543) or visit www.HomeDepot.com.