COSTWAY®





EN

DE

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com

FR



ES

PL

| IT |



COSTWAY www.costway.com

Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

Warnings:

Attention! Use it with protective equipment.

Attention! Not use it in the traffic.

Attention! The product is not suitable for the children under 3 years.

General Warnings:

 ${\ensuremath{\vartriangle}}$ The product must be installed and used under the supervision of an adult.

▲ Read through each step carefully and follow the proper order.

▲ Remove all packaging, separate and count all parts and hardware.

▲ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.

 \triangle We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

 \triangle Ensure a secure surface during construction, und place the product always on a flat, steady and stable surface.

 \triangle Please use the product carefully, as the product requires great skill, avoid accidents by the user or others, by fall or collision.

 \triangle Please wear suitable protective equipment during use, e.g. protective helmet, gloves, knee pads, elbow pads etc.

OWNER'S MANUAL

Please read entire manual before starting assembly. Keep this manual along with your purchase receipt for future reference.

> WARNING: CHOKING HAZARD-Small parts. Not for children under 3 yrs.

MARNING: Toy must be assembled by adult before use.

GENERAL MOTORS TRADEMARKS USED UNDER LICENSE TO JIAXING HARLEY BABY CAR CO.LTD

CAUTION Screws contain potentially hazardous sharp points or sharp edges. Adult assembly required.



To reduce the risk of injury, adult's supervision is required. Never use on road ways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes, and never allow more than two riders.

COSTWAY www.costway.com

IMPORTANT

You must charge your battery for 12 hours before you use your vehicle for the first time.

Remember to. . .

 \checkmark Charge the battery immediately after each use.

✓ Charge the battery at least once a month during storage, even if the vehicle has not been used.

The battery will be permanently damaged and void your warranty if you fail to follow the instructions. Please refer to the Battery Care Section in this manual for more information.

Important Information

ASSEMBLY.

- Your new vehicle requires adult assembly. Please set aside at least 60 minutes for assembly.
- You must charge your battery for 12 hours before you use your vehicle for the first time.
- Read this manual carefully for important safety information and operating instructions before using your vehicle. Keep these instructions for future reference as they contain important information.
- This vehicle is designed for use on: concrete, asphalt or other hard surfaces; on generally level terrain; by children ages 3 and up.
- Instruct the children on operation and safe driving rules before they take their first drive:
 - always sit in the seat.
 - always wear shoes.
 - maximum two (2) riders at a time.
 - do not place hands, feet or any part of the body, clothing or other articles near moving parts while the vehicle is in operation.
 - do not allow other children near the car when driving.
- Use this vehicle ONLY outdoors. Most interior flooring can be damaged by riding this vehicle indoors.

- To prevent damaging the motors and gears, do not tow anything behind the vehicle or overload it. Do not exceed the maximum weight capacity of 88 lbs. (40 kg).
- IMPORTANT INFORMATION: YOUR NEW VEHICLE REQUIRES ADULT ASSEMBLY. PLEASE SET ASIDE AT LEAST 60 MINUTES FOR

Warning

To Prevent Serious Injuries

- This product is intended for use by children ages 3 and up, and is not intended for children under 3 years of age due to lack of ability to operate safely.
- Maximum weight 88 lbs. (40 kg). Maximum 2 riders at a time.
- Do not leave children unattended. Adult supervision required.
- This package contains small parts. Keep away from the children until assembled.
- Read manual for detailed safety information prior to use.
- Inspect product at regular intervals for wear or loose hardware and tighten as required. Remove from service if any abnormal conditions such as cracks or breaks exist.
- Check all coverings regularly to make sure they are in place.
- Batteries can fall out and injure a child if the vehicle tips over. Always use the battery cover.
- When the temperature falls below 0°F(-18°C), outdoor use of this product is not recommended.
- In extreme cold, plastic materials might lose resilience and may become brittle and crack upon impact. Store in a warmer and protected place.
- Do not operate the vehicle outdoors if it is raining. Keep it in a dry area when not in use.
- Disconnect the battery power supply when the vehicle is not in use to prevent the children driving the car without adult supervision.
- Always make sure the seat is securely attached.
- The charger and battery are not toys and must be regularly examined for damage to the cord, plug, enclosure and other parts.
 In the event of damage, the damage or worn part must not be used until replaced.
- Never modify the electrical system. Use of the wrong type battery or charger could cause a fire or explosion.
- Battery compartment and area under seat are not storage areas. Storing other articles may create a fire hazard. Do not store any articles in or near motor compartment.

Safe Driving Rules

- ADULT SUPERVISION REQUIRED. MAKE SURE CHILDREN KNOW AND FOLLOW THESE RULES FOR SAFE DRIVING.
- Restrict children to safe riding areas:
- Away from swimming pools and other bodies of water to prevent drowning.
- Level ground to prevent tipovers and unintended downhill motion.
- Away from steps, hills, driveways, roads and alleys.
- Teach and learn the safety first: Although most children can master the physical driving skills to control the vehicles, they do not have the mature judgment skills. Never let a child drive at any time without adult supervision, and take the time to carefully evaluate child's skill levels and abilities to operate the vehicle safely. Children can not always recognize the hazards even after instruction. So teach appropriate safety rules before allowing any child to operate vehicle, and remember that THERE IS NO SAFE SUBSTITUTE FOR DIRECT ADULT SUPERVISON.
- Riding rules:
- Always sit on the seat and wear shoes.
- Maximum two riders at a time.
- Do not operate in the street or near moving vehicles.
- Do not operate near bodies of water, obstructions or drop-offs.
- Do not operate on sand, dirt or gravel.
- Do not operate in the dark. Unexpected obstacles could cause an accident.
- Do not operate on inclines or steep slopes.
- Do not operate near flammable vapors (e.g. gasoline, paint thinner, acetone, liquid wax, etc.) Using the vehicle near flammable liquids or vapors could cause an explosion or fire.
- Do not place anything near moving parts such as motors, gears or wheels. Rotating parts can snag hair, fingers, etc., which may cause serious injury.

Battery Warning

ELECTRICAL HAZARD



Battery can fall out and injure a child if vehicle tips over. Always use battery cover.

PREVENT FIRE

- Never modify the electrical system. Alterations could cause a fire resulting in serious injury and could also ruin the electrical system.
- Use of the wrong type battery or charger could cause a fire or explosion resulting in serious injury.
- The battery must be handled by adults only. The battery is heavy and contains sulfuric acid (electrolyte). Dropping the battery could result in serious injury.
- Never allow children to charge the battery.
- Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire resulting in serious injury. Lift and carry the battery by the case only.
- Read the safety instructions on the battery.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charger or the battery until you have replaced the worn or damaged part.



Only use the charger in dry locations.

About Thermal Fuses

• Your 12 volt battery is equipped with a built-in thermal fuse. The thermal fuse is a self-resetting safety device which automatically trips and shuts down operation of the vehicle if the vehicle is overloaded or the driving conditions too severe. Once a fuse has tripped it will automatically reset itself after approximately 10 seconds and allow the vehicle to resume normal operations. To avoid repeated automatic shut downs. do not overload the vehicle by exceeding the 88 lbs.(40kg) maximum weight capacity or by towing anything behind the vehicle. Avoid severe driving conditions, such as driving up very steep slopes or running into fixed objects, which can cause the wheels to stop spinning while power is still being supplied to the motors.

Important Notes

- Your new battery must be charged for at least 12 hours before you use it in your vehicle for the first time.
- You do not need to remove the battery from your vehicle to recharge it.
- The battery must be upright while charging.
- The charger is not a toy.
- Do not short circuit the battery.
- We recommend that you start charging your battery before beginning assembly of your new vehicle.
- Before charging the battery, examine the battery case for cracks and other damage which may cause sulfuric acid (electrolyte) to leak during the charging process.
- If damage is detected, do not charge the battery or use it in your vehicle. Battery acid is very corrosive and can cause severe damage to surfaces it contacts.
- Do not charge the battery on a surface which could be damaged by the acid contained inside the battery. Take precautions to protect the surface on which you charge your battery.
- If your battery is old and will not accept a charge, do not leave it in the vehicle. Always remove a dead battery from the vehicle.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from the toy.

• The supply terminals are not to be short-circuited.

Battery Charging

CAUTION

 Non-rechargeable batteries are not to be recharged. • Make sure the charger connector is matching with the battery connector.



Charge the Battery

The first charge will take about 12 hours.

Tips 1:

- 1. Open the battery charger port (located on the seat of near by).
- 2. Insert the battery charger connector into the charger port.
- 3. Plug the charger into a standard 120V wall outlet, Note: The charger may feel warm during charging. This is normal and not a cause for concern.
- 4. After charging is complete (at least 8-10 hours, but not more than twenty four hours, with the first charge taking about 12 hours) unplug the charger from the wall outlet and unplug the battery connector from the charger port.
- Plug the battery connector into the charger port.
- Plug the charger into a standard wall outlet.
- Only use the 12 volt charger to charge your 12 volt battery.
- Note: if power flow to the wall outlet is controlled by a switch, make sure the switch is "ON".
- Before first-time use, charge the battery for at least 12 hours. Never charge the battery longer than 24 hours.
- Recharge the battery for at least 8-10 hours after each use of your vehicle.
- Do not charge the battery longer than 24 hours.
- Do not charge or store battery upside down. Charging produces explosive gases. Charge away from flames. sparks and lit cigarettes. Charge in a well ventilated area.
- Once the battery is charged, disconnect the battery connector from the charger connector. Unplug the charger from the wall outlet. The battery is now ready to be installed in your vehicle. Please see the following Battery Installation Section for detailed instructions on installing your vehicle:



Battery Replacement

1.Lift the seat. 2.Disconnect the battery connectors. 3.Remove the eight screws on the sides of the battery. 4. Take out the battery from the battery compartments.

Charge the battery same as tips 1.

· Make sure the brand, voltage and frequency of the

· Batteries are to be inserted with the correct polarity.

Tips 2: Charge the battery separately

charger are in accordance with the wall outlet.

The supply terminals are not to be short circuited.

Take out the battery

www.costway.com

Battery Care and Disposal

Care

- · If a battery leak develops, avoid contact with the leaking acid and place the damaged battery in a plastics sealed bag.
- If acid comes in contact with skin or eves, flush with cool water for at least 15 minutes and call a physician immediately.
- If acid is Internally ingested, give water, milk of magnesia or egg whites immediately. Never give emetics or induce • Always remove exhausted batteries from your toy. vomiting. Call a physician immediately.
- · Charge a new battery for at least 18 hours before first use.
- Never charge the battery longer than 24 hours.
- Overcharging or undercharging the battery may shorten battery life and decrease vehicle running time.
- After the first charge, recharge the battery for at least 12 hours after each use. Never charge the battery longer than 24 hours. Charge the battery after each use, regardless of how long the vehicle was used.
- The battery must be upright while charging.
- Do not allow the battery to run down completely before charging.
- · Charge the battery before storing the vehicle. · Charge the battery at least once per month, even if the vehicle has not been used.
- · Leaving the battery in a discharged condition will ruin it.
- If the vehicle will be stored for more than two months, be sure to disconnect the motor harness from the battery.
- Do not store the battery in temperatures above 75° F or below-10° F.
- Prevent the battery from moving freely inside the battery. compartment. Make sure all screws for battery cover tighten.
- Examine the battery, charger and its connector for excessive wear or damage each time you charge the battery. If damage is detected, do not use the charger or the battery until you have replaced the worn or damaged part.
- Remember to remove an exhausted battery from the vehicle.
- Battery leakage and corrosion can damage the vehicle.


TO PROLONG BATTERY LIFE, YOU MUST RECHARGE THE BATTERY AFTER EACH USE. YOU MUST ALSO CHARGE YOUR BATTERY IF IT HAS NOT BEEN USED FOR 30 DAYS OR MORE.

Disposal

- · Your battery is a sealed lead-acid battery. It must be recycled or disposed of in an environmentally sound manner.
- · Never dispose your battery in the regular, household trash. The incineration, landfilling or mixing of sealed lead-acid batteries with household trash is prohibited by law in most areas.
- Dispose of dead batteries properly. Never burn or bury them.
- Do not dispose of a lead-acid battery in a fire. The battery may explode or leak.

Parts Diagram

www.costwav.de




Note: Some parts shown are assembled to both sides of the vehicle.

No. Part	Quantity	No. Part	Quantity	No. Part	Quantity
1. Front Bumper	1	9. Rear Wheel (size no.: 15 hole) 2		17. Battery Box	1
2. Front Support Frame	1	10. Door	2	18. Steering Wheel	1
3. Front Axel Assembly 1		11. Rear Bumper Support Frame 1		19. Rearview Mirror	2
4. Front Wheel (size no.:12 hole) 2		12. Rear Bumper	1	20. Dashboard	1
5. Wheel Cover	4	13. Rear Door	1	21. Windshield	1
6. Rear Axel (Diameter: 15m	m) 1	14. Rear Light	2	22. Main Body	1
7. Side Support Frame	2	15. Rear Window	1	24. Hood	1
8. Drive motors	2	16. Seat	1		

Parts List


- Please identify all parts before assembly and save all packaging material until assembly is completed to
 ensure that no parts are discarded.
- Metal parts have been coated with lubricant for protection during shipment. Wipe all metal parts with a paper towel to remove any excess lubricant.




MARNING

Children can be harmed by small parts, sharp edges and sharp points in the vehicles unassembled state, or by electrical items. Care should be taken in unpacking and assembling the vehicle. Children should not handle parts, including the battery, or help in the assembly of the vehicle.


0



Insert the rear bumper support frame under the main body. Fasten it with 11 screws.



 Insert the side support (left) under the main body as picture show above, and fasten it with 7 screws. (The same steps for the right)



Assemble all the parts in sequence as


picture shown. Insert a pin to the hole of

a plier. "Snap" a hubcap into the center.

Repeat the process for the other side.

the front axle and make it to "M" shape by

Front Wheel Assembly




Rear Wheel Assembly Assemble all the parts in sequence as picture shown. Insert a pin to the hole of the rear axle and make it to "M" shape by a plier. "Snap" a hubcap into the center. Repeat the process for the other side.

- 11


COSTWAY www.costway.de

Assembly



- "Snap" the wheel cover into the right place, Repeat the process for the other three wheels.
- Plug connectors.Place the steering wheel onto the turning shaft, press it to the right place.


Assembly




• Insert the seat to the slots of the main body.Press the backrest to the right place.



Spot lights Assembly. Insert the light to the slot of the rear window. (picture is the right one). Repeat the process for the other one.



Insert the windshield to the slots on the main body and fasten with 2 screws.




Battery Assembly Plug connect as the picture shows.

- 12 -



Rear window Assembly Insert the window to the slot of the main body.Press each side to the right place.



• Insert the rearview mirror to the slots of the main body. Repeat the process for the other side.

- 13 -

Operating your Vehicle

Forward

Push the shifter in upward position and press the accelerator slowly.

Reverse

Push the shifter in downward position and press the accelerator slowly.

Low speed

Vehicle has been pre-set to operate at low speed (2.5 mph, (4 kmh) maximum). Once your child has mastered safe driving skills and understands the Safe Driving Rules.

High speed

Vehicle to be driven at the higher speed (5 mph. (8 kmh) maximum) as well as the the lower speed (2.5 mph, (4 kmh) maximum). Make sure your child can safely steer and operate the vehicle and knows the rules for safe driving.

Stop

Vehicle will automatically stop after the accelerator is released.

Sound effect

Press the bottons on the sides of the steering wheel. Each button will make a different sound effect.

Port for MP3


Turn on the power switch. Plug in MP3 cable. Adjust volume as needed.

Safety device


AUTO POWER OFF. If the motor is overloaded for any reason, including improper usage, an electrical circuit breaker will automatically cut off the power, then resume after the parts have cooled!


Maintenance

- · Clean with a dry, soft cloth only. Do not wash with water or corrosive agents.
- Store vehicle in a dry area when not in use, since moisture could cause the metal components and electrical parts to corrode.
- · Remember to charge the battery monthly while the vehicle is not in regular use.
- Check and tighten all screws and coverings regularly.
- Check all plastic parts for cracks. Replace as necessary.



Forward & Reverse





Trouble Shooting

- 15

Trouble Shooting

Problem	Possible Cause	Solution	
Short operating time (less than 1 hour per charge)	Undercharged battery	A new battery should have been charged for at least 12 hours before using the vehicle for the first time. After that, it must be recharged the battery for at least 8-10 hours after each use .Never charge longer than 24 hours. Check all connectors; make sure the charger is plugged into the wall. Make sure the power flow to the outlet is on.	
	Overcharge battery	Never charge battery longer than 24 hours.	
	Old battery will not accept a full charge	Even with proper care, a rechargeable battery does not last forever. Average battery life is 1 to 3 years depending on vehicle use and use conditions. Replace the battery with a new 12 volt rechargeable battery.	
Vehicle is sluggish	Undercharged battery	A new battery should have been charged for at least 12 hours before using the vehicle for the first time. After that, it must be recharged for at least 8-10 hours after each use .Never charge longer than 24 hours.Check all connectors; make sure the charger is plugged into the wall. Make sure the power flow to the outlet is on.	
	Battery needs charging	Be sure to charge the battery after each use.	
	Old battery will not accept a full charge	Even with proper care, a rechargeable battery does not last forever. Average battery life is 1 to 3 years depending on vehicle use and use conditions. Replace the battery with a new 12 volt rechargeable battery.	
	Vehicle is overloaded	Allow no more than 2 rider at a time, follow the 88 lbs. (40 kg) weight capacity and don't tow anything behind the vehicle.	
	Driving conditions are too stressful	Use only on a generally level ground.	

Trouble Shooting

Problem	Possible Cause	Solution
Intermittent vehicle operation	Loose wire or connector	Check all wires around the motors and all connectors to make sure they are tight.
When the go foot pedal is pressed, the vehicle won't run without a push	Loose wire or connector	Check all wires around the motors and all connectors to make sure they are tight.
Charger get warm during use	This is normal and should not be a concern.	No action required.
Battery makes gurgling or sizzling noise while charging	Some noise and swelling is normal and should not be a concern	No action required. If the battery does not make noise while charging. It does not mean it isn't accepting the charging.



Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE! US office: Fontana, California UK office: Ipswich



- *** Reward Points**
- *** Exclusive Customer Service**
- * Personalized Recommendations
- ***** Permanent Shopping Cart
- * Order History

5 Star Rating

We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

