

Model #DVBRUSH12K/10RHD



# Use and Care Guide

## Flexible Duct Cleaning Kit

**EVERBILT**

## Safety Information



**WARNING:** To reduce the risk of fire or injury to persons; follow basic precautions, including the following:

- 1) Rotate brush/rod assembly only in a clockwise direction.  
Reversing the direction could cause the brush head or rod(s) to detach inside the duct.
- 2) Never force the brush/rod assembly through the duct! If it should become jammed, pull assembly away from constricted area a few inches (still rotating in a clockwise direction) then slowly push forward.

### SAVE THESE INSTRUCTIONS

#### NOTICE:

- Removes dangerous lint build-up
- Reduces drying time
- Helps extend the life of your dryer
- Helps prevent dryer fires
- Saves energy, saves money
- Easy to use
- Flexible rods reach up to 12 feet

#### PREP:

- Unplug and move dryer away from wall
- Remove connecting duct from dryer and wall vent
- Remove or open exterior vent hood to allow lint to be pushed out as you clean from inside

## HARDWARE INCLUDED



Brush Head




Flexible Rods

## Installation


### 1 DUCT CLEANING FROM INSIDE

- Connect the brush head to a rod. Start with one rod and add rods one at a time as needed. Secure connections with duct tape.




### 2 DUCT CLEANING FROM BEHIND DRYER

- Insert brush/rod assembly into wall through duct opening where dryer was connected. Attach a drill for more effective cleaning.



### 3 CLEANING

- Turn in a clockwise direction. Gently push and pull brush/rod assembly 12" at a time. Repeat until duct is clean.



## Warranty

### WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

### WHAT IS NOT COVERED

This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit [www.HomeDepot.com](http://www.HomeDepot.com).