7. Turn the municipal water supply back on and open the shut-off valve. Check for leaks. Test the SumpJet to ensure that it is operational by filling the sump pit with water from a garden hose or bucket.
8. Re-connect primary electric sump pump to power supply.
9. If sump cover is desired, it will be necessary to add additional holes and slots to make access for the SumpJet suction pipe and float rod. Refer to the template provided in Figure 4.
10. If the SumpJet cannot be mounted to the primary sump pump discharge pipe, a piece of wood may be used to mount the SumpJet. Cut holes as per Figure 4. There are four screw holes to fasten the SumpJet to the wood. Use #8 x 2.5" long wood screws. Refer to Figure 3.




Figure 3. Alternate SumpJet Installation

Warranty

Liberty Pumps Wholesale Products Limited Warranty

Liberty Pumps, Inc. warrants that Liberty Pumps wholesale products are free from all factory defects in material and workmanship for a period of three (3) years from the date of purchase (excluding batteries). The date of purchase shall be determined by a dated sales receipt noting the model and serial number of the pump. The dated sales receipt must accompany the returned pump if the date of return is more than three years from the date of manufacture noted on the pump nameplate.

The manufacturer's sole obligation under this Warranty shall be limited to the repair or replacement of any parts found by the manufacturer to be defective, provided the part or assembly is returned freight prepaid to the manufacturer or its authorized service center, and provided that none of the following warranty-voiding characteristics are evident:

The manufacturer shall not be liable under this Warranty if the product has not been properly installed, operated, or maintained per manufacturer instructions; if it has been disassembled, modified, abused, or tampered with; if the electrical cord has been cut, damaged, or spliced; if the pump discharge has been reduced in size; if the pump has been used in water temperatures above the advertised rating; if the pump has been used in water containing sand, lime, cement, gravel, or other abrasives; if the product has been used to pump chemicals, grease, or hydrocarbons; if a non-submersible motor has been subjected to moisture; or if the label bearing the model and serial number has been removed.

Liberty Pumps, Inc. shall not be liable for any loss, damage, or expenses resulting from installation or use of its products, or for indirect, incidental, and consequential damages, including costs of removal, reinstallation or transportation.

There is no other express warranty. All implied warranties, including those of merchantability and fitness for a particular purpose, are limited to three years from the date of purchase. This Warranty contains the exclusive remedy of the purchaser, and, where permitted, liability for consequential or incidental damages under any and all warranties are excluded.

Copyright © Liberty Pumps, Inc. 2018 All rights reserved.