


Item # 1002945991 Model #SK17787Cr2-EBW Item # 1002945993 Model #SK17787Cr2-EBB Item # 1002945989 Model #SK17787Cr2-EBG

## **USE AND CARE GUIDE**

## **KITCHEN CART**





Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 1-800-466-3337 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

#### **HOMEDEPOT.COM**

THANK YOU

We appreciate the trust and confidence you have placed in Home Depot through the purchase of this KITCHEN CART. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

## **Table of Contents**

Table of Contents	2
Safety Information	2
Warranty	
What is Covered	
What is Not Covered	2
Pre-installation	3
Planning Installation	

## **Safety Information**

## **DANGER**

- Keep small parts away from children during П assembly
- Read and follow instructions carefully

## WARNING

- Product not intended for use by children under 12.
- Do not exceed 20 pounds per drawer
- Do not exceed Unit maximum load of 50 pounds
- Do not step, stand, or climb on unit
- Always lock castors when unit is stationary
- Add child safety devices if small children live or П frequently visit your home
- Open only one drawer or compartment at a time

Tools required	3
Hardware Included	3
Package Contents	4
Installation	5
Operation	6



- Place heavy objects on the lowest shelf.
- Push mobile units in long direct.
- Inspect castors regularly, if damaged or severely worn, replace castors.
- Units filled with more weight are harder to move and control.
- Electrical items cords should be removed from outlets and secured before moving your cart.
- Use caution when moving over surfaces with П bumps, example, transitioning between different flooring surfaces.

## Warranty

#### **1 YEAR WARRANTY**

#### WHAT IS COVERED

We warrant the Kitchen Cart to be free of manufacturing defects to the original purchaser for one year.

#### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.


Contact the Customer Service Team at 1-800-466-3337 or visit www.HomeDepot.com.

## **Pre-installation**

#### **PLANNING INSTALLATION**

Keep children and pets away from build area, make sure your area is large enough to unpack, sort and assemble the unit.


#### **TOOLS REQUIRED**



#### **HARDWARE INCLUDED**



NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	Single hook	2
BB	5/8 in. Round head screw	8
CC	1-1/2 in. Bolt	2
DD	Magnet	2
EE	Wood dowel	30
FF	1 in. Flat head screw	18
GG	Cam lock bolt	30
HH	Cam lock	30

Part	Description	Quantity
II	Long plastic cover	4
JJ	Short plastic cover	8
KK	Shelf support	8
LL	Handle	4
MM	Handle bolt	8
NN	1/2 in. Flat head screw	8
00	PVC sticker	2

## **Pre-installation (continued)**

#### **PACKAGE CONTENTS**




Part	Description	Quantity
Α	Left side frame	1
В	Right side frame	1
C	Metal towel bar	1
D	Bottom partition	1
E	Top partition	1
F	Fixed panel	1
G	Back panel	2
Н	Bottom panel	1
I	Universal wheel	2
J	Universal wheel with brake	2
K	Top panel	1
L	Adjustable shelf	2
М	Left door	1
N	Right door	1
0	Drawer front panel	2
Р	Drawer left side panel	2
Q	Drawer right side panel	2
R	Drawer back panel	2
S	Drawer bottom panel	2

## Installation



 $\square$  **a)** Attach bar (C) to frame (A) with bolt (CC).





If you choose not to have the function of the towel bar, please use the **PVC sticker(OO)** provided in hardware pack to cover the hole.

□ **b)** Attach hook (AA) to frame (B) with screw (BB) as shown.

# **2** Attaching the magnet

Attach two magnets (DD) to partition (D) with screw (BB) as shown.










# Attaching the top partition to fixed panel

 $\square$  **a)** Join partition (E) to panel (F) with dowel (EE) first.




□ **b)** Tighten panel (F) with screw (FF) as shown.





#### Attaching the bottom partition to 4 fixed panel


□ **a)** Install bolt (GG) and dowel (EE) into panel (F).




□ **b)** Insert lock (HH) into partition (D)

7

**C)** Join partition (D) to panel (F).



□ **d)** Tighten bolt (GG) with lock (HH) in the pre-drilled holes.






(EE) x 4


(**GG**) x 4

# Attaching the back panel and the bottom panel


□ **a)** Join both panels (G) with dowel (EE) and Insert lock (HH) into panel (G).



**b)** Install bolt (GG) and dowel (EE) into panel (H).




□ C) Insert lock (HH) into partition (D).




(**HH**) x 4


(II) x 2

d) Join panel (H) to assembled body with dowel (EE) first.




□ **e)** Tighten bolt (GG) with lock (HH) in the pre-drilled holes.





9 HOMEDEPOT.COM


Please contact 1-800-466-3337 for further assistance.






## Assembling the universal wheel


□ Insert wheel (I) and (J) into frame (A) and (B) as shown.





## Attaching the adjustable shelf

□ Insert shelf support (KK) in the desired position and then place the adjustable shelf (L) on the support.




Shelf support

(**KK**) x 8




# Attaching the door

- $\hfill\square$  Attach door (M) and door (N) to the assembled body with screw (NN) as shown.
- □ Attach handle (LL) to door (M) and door (N) with the handle bolt (MM).



Note: Metal plate needs to be to the top.

Note: Handle the door in position with assistance from a helper could better install the door.





□ **a)** Tighten panel (P) and (Q) to panel (0) with screw (FF).  $\Box$  C) Tighten panel (R) to the assembled body with screw (FF) .

Q (P FF  $\square$  **b)** Slide panel (S) into the grooves on panel (P) and (Q). □ **d)** Tighten handle (LL) to panel (0) with bolt (MM). MM  $(\mathbb{S})$ LL Small head 1 in. Flat head screw Handle Handle bolt (FF) x 16 (MM) x 4



O DOD


(LL) x 2

a

Please contact 1-800-466-3337 for further assistance.



Insert two drawers into the assembled body as shown.



When removing the drawer, tip-up the safety release tab to remove the drawer from the body.

Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 1-800-466-3337 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

#### HOMEDEPOT.COM

Retain this manual for future use.

# IMPORTANT

# Easy step-by-step interactive 3D instructions for this product can be found in



# BILT. INTELLIGENT INSTRUCTIONS



Available on most iOS and Andriod devices

# DOWNLOAD THE FREE APP

