

PVC Inflatable Tent Complete Care & User Manual

Before Setup (ATTENTION)

Carefully check all received parts against the ACCESSORY list.

If any part is missing or damaged, contact the seller immediately. Specify the part needed and provide clear photos for damage claims.

Setup Instructions

Unfold & Anchor:

Unfold the tent on your chosen site. Fix the 4 corner/base positions firmly to the ground using tent pegs.

Connect Pump:

Locate the air inlet valve. Connect the nozzle of the pressure - limiting pump securely to the valve.

Inflate:

Pump continuously for 3 to 5 minutes, or until the tent is fully expanded and the air columns feel firm to the touch. Do not over - inflate.

Final Securing:

Insert all remaining tent pegs around the base. Attach and tighten all 6 wind ropes to their respective anchors (tent pegs or stakes placed away from the tent).

Attach Canopy:

Connect the canopy to the main tent structure using the provided zippers, and support it with the 2 tent poles.

Care & Cleaning Instructions

Cleaning (PVC Specific):

Wipe down with a mild soap solution and a soft cloth or sponge. Avoid abrasive cleaners or brushes that could scratch the PVC coating.

Rinsing & Drying:

Rinse thoroughly with clean water. Air dry completely in a shaded area before packing. Sun - drying for extended periods may degrade PVC over time.

Zipper Care:

Keep zippers free of dirt and sand. Occasionally lubricate with a silicone - based zipper lubricant.

Mold/Mildew:

If mildew appears on non - PVC parts (e.g., canopy fabric), use a diluted vinegar solution. For PVC, use a specialized PVC cleaner.

Storage Instructions

Mandatory Condition:

Store only when completely dry. Moisture trapped with PVC can promote mold growth on fabrics and damage coatings.

Packing:

Fold or roll the tent neatly. Avoid creasing the air columns sharply.

Location:

Store in the provided bag in a cool, dry, dark, and well - ventilated place. Avoid extreme heat and direct sunlight for long - term storage, as these can make PVC brittle.

Prolonging Tent Life (Recommendations)

Use a Groundsheet:

Placing a separate ground cloth or tarp underneath is strongly recommended to protect the PVC floor from punctures, abrasion, and dirt.

Site Prep:

Always clear the ground of sharp stones, sticks, and debris.

Regular Inspection:

Check for punctures, seam integrity, and valve condition periodically. Clean off any dirt, leaves, or pine needles after each use.

Important Warnings

Pump is Specific:

Use only the provided pressure - limiting pump to avoid over - inflation and potential rupture of PVC seams.

PVC Considerations:

PVC can become less flexible in very cold temperatures and more susceptible to damage. Handle with care in cold weather.

Avoid Hazards:

Keep away from open flames, sparks, high heat sources (like grills), and sharp objects.

Never Store Wet:

This is critical to prevent mold and material degradation.

Contact for Support:

For missing parts or significant damage, contact the seller with clear photos and details.