


# **USE AND CARE GUIDE**

## **ROSEBROOK 7PC DINING SET - TABLE**



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

## HOMEDEPOT.COM/HOMEDECORATORS

#### THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Home Decorators Collection!

## **Table of Contents**

Table of Contents	2
Important Safety Instructions	2
Save These Instructions	2
Read All Instructions before Use	
Warranty	3
What is covered	3
What is not covered	3

Pre-Assembly														3
Planning Assembly														3
Hardware Included														3
Package Contents														4
Assembly														
Care and Cleaning														6

# **Important Safety Instructions**

### SAVE THESE INSTRUCTIONS



WARNING: This table was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and/or covering this product when any formidable/severe weather is approaching.



**WARNING:** Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is not intended for commercial use and will void the warranty.

#### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this table is used by or near children, or disabled persons, if applicable.
- Use this table only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the table while it is occupied. Failure to obey this caution could result in injury.
- 4. This table is not intended to support an umbrella. Umbrellas must have a suitable base or stand.



**CAUTION:** When not in use, secure the product in a cool and covered location.



**CAUTION:** Do not locate the product near any heat sources.



**WARNING:** Please keep children out of the assembly area before assembly.



**WARNING:** This table is heavy, and may require two adults for safe assembly.



**WARNING:** Never use this product as a support. Do not shake, lean, or climb on the product at any time.



**WARNING:** Do not place heavy objects on the table.

# Warranty

### **5 YEAR FRAME LIMITED WARRANTY**

### WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years.

## WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-800-986-3460 or visit HOMEDEPOT.COM/HOMEDECORATORS.

# **Pre-assembly**

### PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

### HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6 x 15 Combination Bolt	10+1
BB	Hex Wrench	1

# **Pre-assembly (continued)**

# **PACKAGE CONTENTS**




Part	Description	Quantity
Α	Table Top	1
В	Table Leg	2
С	Support Tube	1
D	Umbrella Ring	1

# **Assembly**


# Attaching the Table Legs to the Table Top

- □ Place the table top (A) upside down on a soft surface.
- □ Attach the table legs (B) to the table top (A) using M6 x 15 combination bolts (AA).
- □ Do not tighten all bolts at this step.



# **2** Attaching the Support Tube to the Table Legs and the Table Top


- □ Attach the support tube (C) to the table legs (B) and the table top (A) using M6 x 15 combination bolts (AA).
- Once all of the bolts are in place, fully tighten the bolts using the hex wrench (BB).



# **Assembly (continued)**

# 3 Checking the Table

- □ Turn the table right side up.
- □ Place the umbrella ring (D) to finish the assembly of the table.
- Ensure the table is tightly assembled and stable before use.



# **Care and Cleaning**

- □ For best results, clean the table with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- □ Store the table in a dry, sheltered place when not in use.
- □ Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

## HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.


For certification use only

Factory table ID # FTA81369



# **USE AND CARE GUIDE**

## **ROSEBROOK 7PC DINING SET - CHAIR**



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

### HOMEDEPOT.COM/HOMEDECORATORS

#### THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Home Decorators Collection!

## **Table of Contents**

able of Contents	Pre-Assembly
mportant Safety Instructions2	Planning Assembly
Save These Instructions	Hardware Included
Read All Instructions before Use	Package Contents
Varranty	Assembly
What is covered	Care and Cleaning
What is not covered	·

# **Important Safety Instructions**

### SAVE THESE INSTRUCTIONS



WARNING: This chair was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and/or covering this product when any formidable/severe weather is approaching.



**WARNING:** Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is not intended for commercial use and will void the warranty.

### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this table is used by or near children, or disabled persons, if applicable.
- Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Please keep children out of the assembly area before assembly.



**CAUTION:** When not in use, secure the product in a cool and covered location.



**CAUTION:** Do not locate the product near any heat sources.



WARNING: Weight limit for chair is 250 lb (113.38 kg).



WARNING: Do not place heavy objects on the chair.

# Warranty

## **5 YEAR FRAME AND 5 YEAR FABRIC LIMITED WARRANTY**

### WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for five years, and a five year limited warranty for the fabric.

## WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-800-986-3460 or visit HOMEDEPOT.COM/HOMEDECORATORS.

# **Pre-assembly**

### PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

### HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6 x 20 Combination Bolt	6+1
BB	Hex Wrench	1

# **Pre-assembly (continued)**

# **PACKAGE CONTENTS**




Part	Description	Quantity
Α	Chair Frame	2
В	Chair Base	2
С	Back Cushion	3
D	Seat Cushion	3

# **Assembly**


# **1** Attaching the Chair Base to the Chair Frame

- □ Place the chair frame (A) upside down on a soft surface.
- □ Attach the chair base (B) to the chair frame (A) using M6 x 20 combination bolts (AA).
- Once all bolts are in place, fully tighten all bolts using the hex wrench (BB).



# **2** Checking the Chair

- □ Turn the chair right side up.
- □ Place the seat cushion (D) and the back cushion (C) to finish the assembly of the chair.
- □ Ensure all connections are secure before use.



# **Care and Cleaning**

For best results	, clean	the chair	with a da	amp cloth	and dr	y thoroughly.	This will	help pre	vent milde	w by rer	noving d	irt particle	s that
may accumulate	€.												

 $\hfill\Box$  Do not clean with abrasive materials, bleach, or solvents.

 $\hfill\Box$  Store the chair in a dry, sheltered place when not in use.

□ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

## HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.

For certification use only

Factory chair ID # FRA81324