

# # 39552 Replacement Vacuum Bags



Remove the old bag and seal the opening using the adhesive flap and discard. Expand the new bag and place it inside the canister with the opening facing the stem inside the vacuum. Slide the rubber gasket onto the stem until it finds the ridge in the stem. Change bag when debris reaches six inches inside the bag or when there is a noticeable reduction in airflow. Replace the canister lid and make sure it fits properly to the body of the canister to prevent vacuum leaks.

For further questions regarding this product and its intended uses please contact Cen-Tec Systems by email: [help@centecsystems.com](mailto:help@centecsystems.com) or call 1-800-833-2822 between the hours of 8:00am and 5:00pm Monday through Friday CST