USE AND CARE GUIDE

COASTER FINE FURNITURE | coasterfurniture.com

Product	48 in. Rectangular White 2 Drawer Computer Desk with File Storage
Model / SKU	800110 (Home Depot Internet # 310363253)
Finish	White
Dimensions	47.25 in. W x 23.5 in. D x 29.5 in. H
Materials	Melamine paper veneer and engineered wood (MDF, PB)

Customer Service

Warranty claims, missing, damaged or defective parts, or assembly help	Contact Coaster: email **ecomm06@coasteramer.com** or call **(888) 710-5274**. Where the assembly instructions say to contact the store, contact Coaster instead. Have your model number (800110) and proof of purchase ready.
Returns and refunds	Contact The Home Depot, where you purchased this item.

Assembly and Safety

- Assembly instructions follow on the next pages. Check that all parts and hardware are present before you start.

Care and Cleaning

- Dust often with a soft, dry, lint-free cloth, following the grain.
- Wipe up spills right away with a soft cloth lightly dampened with water, then dry the surface.
- Do not use abrasive cleaners, ammonia, solvents or silicone polishes.
- Use felt pads under lamps and decor, and coasters or mats under hot, cold or wet items.
- Keep out of direct sunlight and away from heaters, fireplaces and air vents. Sudden changes in heat or humidity can affect wood and finishes.
- To move it, lift it; do not drag it.

Limited Warranty

- Coaster warrants this product to be free from manufacturing defects in workmanship and materials for one (1) year from the date of purchase.
- Covers residential use only. Industrial, commercial, institutional and rental use are not covered.
- Does not cover color variations, size discrepancies, normal wear or buyer’s remorse.
- Void if damage results from improper use or maintenance, unauthorized modifications, assembly not done according to the instructions, moving the item after delivery, accidents or abuse.
- To make a warranty claim, email Coaster at ecomm06@coasteramer.com or call (888) 710-5274 with your model number and proof of purchase.
- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

800110
OFFICE DESK

REVISION 0: 01/31/2018
REVISION 1: 08/31/2018
REVISION 2: 06/17/2019
REVISION 3: 07/12/2022

ITEM:**800110**


ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.















WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 50 MINUTES

PARTS IDENTIFICATION


A	LEFT SIDE PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC
C	BOTTOM PANEL		1 PC
D	SMALL TOP PANEL		1 PC
E	BACK PANEL		1 PC
F	LARGE DRAWER FRONT PANEL		1 PC
G	LARGE DRAWER BACK PANEL		1 PC
H	LARGE LEFT DRAWER SIDE PANEL		1 PC
I	LARGE RIGHT DRAWER SIDE PANEL		1 PC
J	DRAWER BOTTOM PANEL		2 PCS
K	SMALL DRAWER FRONT PANEL		1 PC
L	SMALL DRAWER BACK PANEL		1 PC
M	SMALL LEFT DRAWER SIDE PANEL		1 PC
N	SMALL RIGHT DRAWER SIDE PANEL		1 PC
O	SMALL CROSS BRACE		1 PC
P	LARGE TOP PANEL		1 PC
Q	SIDE PANEL		1 PC
R	DIVIDER PANEL		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





ITEM:**800110**




COASTER FINE FURNITURE

S	LARGE CROSS BRACE		1 PC

Z

HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC
2	WOODEN DOWEL Ø 8x30mm		29 PCS
3	CAM BOLT Ø 7x35.5mm SR		17 PCS
4	CAM LOCK Ø15x12mm SR		17 PCS
5	BOLT Ø9.5x55mm SR		8 PCS
6	DRAWER SCREW Ø4.3x35mm SR		8 PCS
7	RAIL L = 400mm WHT		2 SET
8	RAIL SCREW Ø 3x12mm SR		28 PCS


NO	DESCRIPTION	FIGURE	Q'TY
9	PLASTIC FEET Ø 15mm		2 PCS
10	HANDLE L=120mm		2 PCS
11	HANDLE BOLT Ø 4x28mm SR		4 PCS
12	FOOT 50x50x18mm		4 PCS
13	FOOT SCREW Ø 5x23mm SR		8 PCS
14	IRON BAR Ø 9.5x402mmSR		2 PCS
15	STICKER Ø 20mm		4 PCS


Z7,Z10,Z11,Z12,Z14 not included in blister packaging.

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM:**800110**


STEP 1






Apply glue on all wooden dowels to ensure integrity of the structure.










ITEM:**800110**

STEP 2







Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 3







Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**800110**

COASTER FINE FURNITURE

STEP 4






Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 5







ITEM:**800110**

COASTER FINE FURNITURE

STEP 6


LEFT





STEP 6


RIGHT



ITEM:**800110**


STEP 7

LEFT



STEP 7

RIGHT





ITEM:**800110**

COASTER FINE FURNITURE


STEP 8

LEFT






Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 8

RIGHT





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**800110**


STEP 9

LEFT






Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 9

RIGHT





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:**800110**

STEP 10


LEFT






STEP 10

RIGHT




ITEM:**800110**

STEP 11





ITEM:**800110**

STEP 12



Insert rails in outside holes for large files.
Insert rails in inside holes for small files.






ITEM:**800110**

STEP 13


LEFT



STEP 14


LEFT

COMPLETE



STEP 13


RIGHT




STEP 14


RIGHT


COMPLETE



ITEM:**800110**







Note : Dimension tolerance ±5%