


# REPLACEMENT PARTS - MODEL TB25PS

## 2-CYCLE POLE SAW

PPN 41AD25PS766




Item	Part No.	Description	Item	Part No.	Description
1	753-10406	Rear Cover Assembly (includes 2 & 3)	18	753-06417	Air Cleaner Filter
2	791-182195	Rear Housing Screw	19	753-06183	Fuel Tank Assembly (includes 20 & 21)
3	710-04194	Cover Screw	20	791-182612	Fuel Tank Cap
4	841-014182S	Short Block Assem. (incl. 5 - 11, 32 & 34)	21	791-181930	Fuel Tank Screw
5	753-06847	Spark Plug	22	753-05860	Clutch Assembly
6	753-09085	Crankcase O-Ring	23	841-014381S	Starter Housing (includes 2 & 24)
7	710-06241	Crankcase Bolt	24	791-182366	U-shaped Nut
8	753-09125	Flywheel Assembly	25	753-10405	Clutch Cover (includes 3)
9	753-06247	Washer	26	791-182519	Anti-rotation Screw
10	750-04434	Spacer	27	2986	Clamp Screw
11	753-10464	Module Assembly	28	712-0161	Clamp Nut
12	753-09105	Insulator Assembly (includes 13 & 14)	29	746-06311	Throttle Cable
13	753-06184	Insulator O-Ring	30	794-00244	Lead Wires
14	721-04972	Carburetor O-Ring	31	841-014184S	Muffler Assembly
15	753-06288	Carburetor	32	841-014301S	Electric Starter Cover Assem. (includes 33)
16	753-06253	Carburetor Gasket	33	753-09086	O-Ring
17	753-10484	Air Cleaner Cover Assem. (includes 18)	34	914-04016	Flywheel Key

# REPLACEMENT PARTS - MODEL TB25PS

## 2-CYCLE POLE SAW

PPN 41AD25PS766



Item	Part No.	Description	Item	Part No.	Description
35	753-06880	Upper Drive Shaft Housing Assembly	51	710-04696	Gearbox Screw
36	753-08344	Throttle Housing Assem. (includes 37 - 40)	52	710-0528	Gearbox Bolts
37	791-182405	Throttle Switch Assembly	53	753-05586	Oil Tank Assembly
38	731-08433C-10	Throttle Trigger Lock-Out	54	753-05587	Fuel Cap Assembly
39	731-04970B-10	Throttle Trigger	55	791-181345	Screw
40	753-05007	Throttle Trigger Spring	56	753-05588	Oil Line
41	753-06039	D-Handle (includes 42)	57	753-05597	Chain Tension Hardware Assembly
42	753-06040	D-Handle Bolt	58	753-05594	Chainsaw Guide Bar
43	753-09225	Split Boom Coupler Assem. (includes 44)	59	753-05592	Chain
44	791-182057	Split Boom Coupler Screw	60	753-05765	Chain Guard
45	753-09226	Extension Boom	61	712-04063	Gearbox Nuts
46	753-05724	Lower Drive Shaft Housing (includes 47)	62	731-05906	Chain Cover
47	791-181852	Flexible Drive Shaft			
48	710-0599	Lower Drive Shaft Screw	*	Optional	
49	753-05595	Sprocket Assembly	*	731-08926	Hanger
50	753-05599	Gearbox Assembly (includes 49 & 51)			