

Product	Descriptions	Instructions
Downspout Extension	<ul style="list-style-type: none"> • Fits all standard residential • Easy Installation! Extend, Bend, Connect & Bury • Connects to other FLEX-A-SPOUT™ accessories • Keeps destructive rainwater away from Foundations 	Choose either the 2x3 or 3x4 end to match the size of your downspout, and install over the outside of the end of your downspout. Bend and stretch to fit your landscape needs. To attach other FLEX-A-SPOUT™ accessories cut the end not attached to the downspout at the cut-here line and snap on your accessory
Downspout Adapter	<ul style="list-style-type: none"> • Connects 2x3 and 3x4 inch downspouts to 3 or 4 inch drainpipes • Extends up to 16 inches • Easy Installation! Extend, Bend, Connect & Bury • Connects to other FLEX-A-SPOUT™ accessories 	Install your downspout adapter over the outside end of your downspout and push up for a snug fit. Attach the rounded cuff end to 3" or 4" Corrugated pipe, 4" PVC or your chose of FLEX-A-SPOUT™ accessories with a simple snap fit.
Extention	<ul style="list-style-type: none"> • Adds up to 8 feet to Downspout Extention • Redirects water for lawn and garden • Easy Installation! Extend, Bend, Connect & Bury • Connects to other FLEX-A-SPOUT™ accessories 	Install the larger rounded end (female end) to the downspout adapter by snapping the two fittings ends together. Connect to your downspout extension by cutting the end not attached to the downspout at the cut here line and snap on your accessory. Attach your choice of FLEX-A-SPOUT™ accessories by snapping them onto the end of the pipe.
Covered Splash Block	<ul style="list-style-type: none"> • Easy to hide under light ground cover • Connects to other FLEX-A-SPOUT™ accessories • Prevents erosion from runoff water • Requires other FLEX-A-SPOUT™ accessory 	Install your covered splash block by attaching it to either the FLEX-A-SPOUT™ downspout adapter or Downspout Extention. Connect to your downspout extension by cutting the end not attached to the downspout at the cut here line and snap on your Splash Block
Low Profile Extender	<ul style="list-style-type: none"> • Connects to Covered Splash Block • Telescoping Extender adds 9 to 28 inches • Easy to hide under light ground cover • Requires other FLEX-A-SPOUT™ accessory 	Attach the Low Profile Extender to your Covered Splash Block by sliding the Extender end over the Splash Block and adjusting to the desired length. Cover with mulch or light ground cover to conseal.
Splash Block	<ul style="list-style-type: none"> • Integrated design stays in place • Prevents erosion from runoff water • Requires other FLEX-A-SPOUT™ accessory • Keeps destructive rainwater away from Foundations 	Attach your Splash Block to either either the FLEX-A-SPOUT™ downspout adapter or Downspout Extention. Connect to your Splash Block by cutting the end not attached to the downspout at the cut here line and snap on your Splash Block