
LG SIGNATURE


LUPXS3186N


QUICK INSTALL & CLEARANCES

For full installation directions/clearances please refer to the corresponding User Manual and Installation Guide.

DI	MENSIONS/CLEARANCES/WEIGH	4T
А	Depth with Handles	36-5/8"
В	Depth without Handles	36-5/8"
С	Depth without Door	30-7/8"
D	Depth (Total with Door Open)	49-1/2"
Е	Height to Top of Case	69"
F	Height to Top of Door Hinge	70-1/4"
G	Width	35 -3/4"
Н	Width (Door Open 90° without Handle	e) 40-1/3"
-1	Width (Door Open 90° with Handle)	40-1/3"
Door Edge Clearance with Handle 2-1/3		2-1/3"
Door Edge Clearance without Handle		2-1/3"
Installation Clearance Top 1", Back 2"		
Weight (Unit/Carton) 483 lbs / 516 lk		
Carton Dimensions (WxHxD) 38" x 73" x		













CONNECTING POWER AND SECURING SPACE FOR WATER SUPPLY PIPE




Power connection


- The location of the 115V 60Hz power connector must be located on the rear side of the product as shown in the picture.
- When installing the product, make sure to check whether the cord is sure to creak whether the cold is hung on the hook on the rear side so that it is not pressed on the refrigerator. Damaged power cord can cause a fire.



Installation space for water supply pipe

Place the water hose for ice maker and water dispenser as shown in the
picture, and prepare hose to come up from the floor. (Copper pipe with
diameter of 5/16"(8mm) is recommended for the water hose.) If the water
pipe and water hose is located far from the product, bury the water hose on
the floor and provide appropriate treatment.







▲ Do not ground the product to gas pipe, plastic water pipe or telephone wire etc. It can cause electric shock and explosion.