
INSTALLATION AND CARE GUIDE


SOAP DISPENSER



Installation


Preparing for installation

 Remove the soap bottle (1) and soap dispenser mounting nut (2). Separate the soap pump (3) from the soap assembly shank (4). Do not lose the washer (5).



2 Installing the soap assembly shank


- Ensure the washer (1) is bottom the soap assembly shank (2).
- Insert the soap assembly shank (2) through the selected hole in the sink.
- Secure the soap assembly shank (2) to the sink with the soap dispenser mounting nut (3) provided. Push up the soap dispenser mounting nut (3) to sink and hand-turn to tighten, as shown in the Fig 1.



Installation (continued)


3 Installing the soap bottle

 From under the sink, screw the soap bottle (1) onto the soap assembly shank (2).



4 Pouring in the soap

 Pour in the soap (not included) into the shank orifice.



5 Installing the soap pump

 Insert the soap pump (1) down into the soap assembly shank (2).

