

Use and Care Manual

Usage: Before cleaning, check whether the broom head is clean and free of foreign matter to ensure the best cleaning effect. Grasp the handle and gently swing the broom to use its wide sweeping path and powerful sweeping head to easily remove dust, trash and particles from the ground.

Cleaning: After use, rinse the broom head with clean water to remove dust and stains. Then let it dry to avoid prolonged dampness.

Avoid heavy weight: Do not press heavy objects on the broom to avoid damage to the broom head or deformation.

Replace the bristles: When the bristles are worn or deformed, it is recommended to replace the new bristles in time to ensure the cleaning effect and extend the service life of the broom.

Storage: Use the hanging ring at the top of the handle to hang the broom in a ventilated and dry place, away from direct sunlight and humidity. This will extend the service life of the broom and keep it clean and organized.