


## **CLEANING AND CARE**

# **LP Gas Outdoor Fireplace**

Model No. GAD1401M



ALWAYS refer to owner's manual for all warnings, safety information, operating instructions, care instructions and troubleshooting.

### **Cleaning and Care**

#### **A** CAUTION:

- 1. All cleaning and maintenance should be done when outdoor fireplace is cool and with the fuel supply disconnected.
- 2. Do NOT clean any outdoor fireplace part in a self-cleaning oven. The extreme heat will damage the finish.
- 3. Do NOT enlarge valve orifices or burner ports when cleaning the valves or burners.

#### **Notices**

- 1. This outdoor fireplace should be thoroughly cleaned and inspected on a regular basis.
- 2. Abrasive cleaners will damage this product.
- 3. NEVER use oven cleaner to clean any part of this outdoor fireplace.

#### **Before Each Use:**

- 1. Keep the outdoor fireplace area clear and free from any combustible materials, gasoline, and other flammable vapors and liquids.
- 2. Do NOT obstruct the flow of the combustion of LP gas and the ventilation of air.
- 3. Keep the ventilation opening(s) of the LP gas tank area free and clear from debris.
- Visually check the burner flames to make sure your outdoor fireplace is working properly (Figure 5).
- 5. See below for proper cleaning instructions.
- 6. Check all gas connections for leaks.
- 7. Check components for any signs of damage or rust.
- 8. Check for obstructions of airflow to the burner. Spiders, insects and webs can clog the burner/venturi tube. A clogged burner/venturi tube can lead to a fire.
- 9. If damage to any component is detected, do NOT operate until repairs are completed.

#### **Cleaning Surfaces**

- 1. Wipe surfaces clean with mild dishwashing detergent or baking soda mixed with water.
- 2. For stubborn stains, use a citrus-based cleaner and a nylon scrubbing brush.
- 3. Rinse clean with water.
- 4. Allow to air dry.

#### **Before Storing**

- 1. Turn LP gas tank valve to "CLOSED."
- 2. Turn control knob to the "△ OFF" position.
  - Note: A "poof" sound is normal as the last of the gas is burned.
- 3. Disconnect LP gas tank per "Disconnecting LP Gas Tank" section.
- Clean all surfaces.
- 5. Lightly coat the burner with cooking oil to prevent excess rusting.

#### **▲ CAUTION: NEVER place cover on hot outdoor fireplace.**

- 6. If storing the outdoor fireplace indoors, cover the outdoor fireplace and store in a cool dry location away from children and pets.
- 7. If storing the outdoor fireplace outdoors, cover the outdoor fireplace with a cover for protection from the weathe