# ROKU REPLACEMENT REMOTE

**SM-ROKU-104**

EMERALD®




① TV MUTE:Cuts off the sound temporarily.

TV POWER: Turn on/off the TV.

BACK:Goes back to previous menu/screen.
Home screen tile: Moves highlight back to the Home screen option.
Watching Antenna TV or a TV input: Returns to Home screen.
Playing streaming content: Stops playing stream and returns to the previous menu or screen.
Browsing streaming content: Goes to the previous level in the content tree.

HOME:Immediately returns to the Home screen.

② INSTANT/REPLAY: Select models Streaming programs that support this feature and broadcast TV if Live TV Pause is enabled, jumps back a few seconds with each press and resumes playing.
Broadcast TV if live tv pause is disabled, jumps to previous channel.
When using an on-screen keyboard, backspaces in the text you are entering.

OPTIONS: Displays additional options when available.

③ Accesses to your favorite channel

NETFLIX,hulu,raio,

vudu,YouTube(Spotify),MGO(SHOWTIME),

Google(HBO NOW),CINEPLEX(CBS NEWS),amazon,sling