
Model #755.0760.000

HAMPTON BAY

USE AND CARE GUIDE

BRAXTON PARK SWIVEL DINING CHAIR



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	Hardware Included
Safety Information	Chair Package Contents
Warranty	Assembly
What is covered	Care and Cleaning
What is not covered	
Pre-Assembly	
Planning Assembly3	


Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We warrant the product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing, or abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production. Contact Customer Care at 1-800-841-1350 or visit www.hamptonbay.com.

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.





 $\ensuremath{\text{NOTE:}}$ More than one person may be required to assemble this product.

HARDWARE INCLUDED





NOTE: Hardware not shown to actual size.





Part	Description	Quantity
AA	M8x40 bolt	4
BB	M6x40 bolt	8
CC	Washer for M8 bolt	4
DD	Washer for M6 bolt	8
EE	Spring washer	4
FF	Nut	4
GG	Bolt cap for nut	8
НН	Bolt cap for bolt AA	8
II	Bolt cap for bolt BB	8
JJ	Hex wrench	2
KK	Allen driver	1
YY	Hex. screw (6 mm)	1
ZZ	Ratchet wrench	1








NOTE: Part YY + ZZ are additional tools, same function as part KK, but more easier to use.

CHAIR PACKAGE CONTENTS



IMPORTANT: Do not fully tighten bolts/screws until all pieces are loosely assembled.



Part	Description	Quantity
Α	Right arm	1
В	Left arm	1
С	Chair seat	1
D	Chair back	1
E	T- rock	1
F	Chair base	1
G	Seat cushion	1
Н	Back cushion	1
I	Metal plate	2


Assembly

Attach the right arm to the chair seat

 Attach the right arm (A) to the chair seat (C) using M6 bolts (BB) and washers (DD).




NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (KK) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic caps (II) after final assembly finished.




Attach the chair back to the right arm

Attach the chair back (D) to the right arm (A) using M6 bolts (BB) and washers (DD).



3 Attach the chair back and left arm to the chair seat

Attach the chair back (D) and left arm (B) to the chair seat (C) using M6 bolts (BB) and washers (DD).



HAMPTONBAY.COM


Assembly (continued)

4 Attach the T-rock to the chair seat

 Attach the T-rock (E) to the chair seat (C) using M8 bolts (AA), metal plate (I), washers (CC and EE), and nuts (FF).




NOTE: Please ensure all the bolts are assembled correctly and use the hex wrench (JJ) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic caps (GG) after final assembly finished.




5 Insert the chair seat to the chair base

□ Insert the chair seat (C) to the chair base (F).



6 Add the cushions

□ Add the seat cushion (G) and back cushion (H).



Care and Cleaning

- □ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- $\hfill\Box$ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.

HAMPTON BAY

USE AND CARE GUIDE

BRAXTON PARK DINING TABLE



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents 2 Safety Information 2	
Warranty	<u> </u>
What is covered	Care and Cleaning
What is not covered	
Pre-Assembly	
Planning Assembly	

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We warrant the product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, freezing, or abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production. Contact Customer Care at 1-800-841-1350 or visit www.hamptonbay.com.

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.



 $\ensuremath{\text{NOTE:}}$ More than one person may be required to assemble this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.




Part	Description	Quantity
AA	M6x15 bolt	16
BB	Washer	16
CC	Bolt cap	16
DD	Allen driver	1

TABLE PACKAGE CONTENTS



 $\textbf{IMPORTANT:} \ \textbf{Do not fully tighten bolts/screws until all pieces are loosely assembled.}$



Part	Description	Quantity
Α	Table top	1
В	Table leg	4


Assembly

1 Attach the table legs to the table top

 $\hfill\Box$ Attach the table legs (B) to the table top (A) using M6 bolts (AA) and washers (BB).



NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (DD) to tighten. Do not fully tighten bolts/screws until all pieces are loosely assembled. Add corresponding plastic caps (CC) after final assembly finished.



2 Turn the table up

 $\hfill\Box$ Turn the table right side up.



HAMPTONBAY.COM

Care and Cleaning

- $\ \square$ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- $\hfill\Box$ Rinse with clean water and dry with a soft, absorbent cloth towel.
- □ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.