









How to use your **FlushIQ™**


Sensor Display Alerts

-  **Blue**
Normal operation-toilet is performing a flush/fill cycle.
-  **Yellow**
Leak detected.
-  **Flashing Yellow**
Leak detected. (Tank fill failure.)
-  **Flashing Red & Blue**
Overflow level detected. Toilet will not flush.
-  **Flashing Red**
Low battery indication.
-  **Flashing Blue**
Toilet is in sleep mode. Toilet will not flush.

How to Change the Batteries


AA Batteries

Remove lid by twisting latch ① and pulling. Install 4 "AA" batteries in orientation shown.



C Batteries


Remove box lid ① and adapter ② to install "C" batteries for longer battery life. Reinstall lid.



Note: Positive terminals are to the left and negative terminals are to the right.

How to Flush Manually

Lift off tank lid and push down on the red, manual flush rod ①. The tank will not automatically refill after manual flush.



Sleep Mode

To enter Sleep Mode:

Touch sensor for 7 seconds. (Toilet will not flush while in sleep mode. Use for cleaning, etc.)

To exit Sleep Mode:

Touch sensor for 7 seconds or wait for the 10 minute time out.

Learn More about FlushIQ™

For more help visit www.deltafaucet.com/toilet. To find product information visit www.deltatoilet.com/FlushIQ or scan the QR code to automatically take you to our product videos.



76688 Rev. A