


USE AND CARE GUIDE

CLOVERMILL 4PC CONVERSATION SET-CHAIR



Questions, problems, missing parts?
Before returning to the store, call StyleWell Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!!

Table of Contents

| | | | |
|------------------------------------|---|-------------------------|---|
| Table of Contents | 2 | Pre-Assembly..... | 3 |
| Important Safety Instructions..... | 2 | Planning Assembly | 3 |
| Warranty | 2 | Hardware Included | 3 |
| What is Covered | 2 | Package Contents | 3 |
| What is not Covered | 2 | Assembly | 4 |
| | | Care and Cleaning | 5 |

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

1 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production. For a copy of our full limited warranty, please contact our customer service team below. Contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Verify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.



NOTE: More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



_ AA




_ BB




_ CC

| Part | Description | Quantity |
|------|-----------------------------|----------|
| AA | M6 x 15 mm combination bolt | 4 |
| BB | M6 x 40 mm combination bolt | 4 |
| CC | M6 Allen wrench | 1 |

PACKAGE CONTENTS




A




B



C



D



E

| Part | Description | Quantity |
|------|--------------|----------|
| A | Front leg | 1 |
| B | Back leg | 1 |
| C | Connect bar | 2 |
| D | Chair frame | 1 |
| E | Seat cushion | 1 |


Assembly

1 Attaching the connect bars to the legs

- Attach the connect bars (C) to the front leg (A) and back leg (B) with the M6 x 15 mm combination bolts (AA) using the M6 wrench (CC).




NOTE: Please ensure all bolts are aligned and assembled correctly. Do not tighten bolts until the frame assembly is complete.




2 Attaching the chair frame to the legs

- Attach the chair frame (D) to the chair legs (A and B) with the M6 x 40 mm combination bolts (BB) using the M6 wrench (CC).
- Once all of the bolts are in place, fully tighten all the bolts.



3 Adding the cushion

- Turn the chair over and set it down on its legs.
- Place the seat cushion (E) on the chair.
- The chair is now ready for use.



Care and Cleaning

- ❑ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- ❑ Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- ❑ Rinse with clean water and dry with a soft, absorbent cloth towel.
- ❑ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

StyleWell™

Questions, problems, missing parts? Before returning to the store,
call StyleWell Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday


1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.

USE AND CARE GUIDE

Clovermill 4Pc Conversation Set-Loveseat



Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this loveseat. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!

Table of Contents

| | | | |
|------------------------------------|---|-------------------------|---|
| Table of Contents | 2 | Pre-Assembly..... | 3 |
| Important Safety Instructions..... | 2 | Planning Assembly | 3 |
| Warranty | 2 | Hardware Included | 3 |
| What is Covered | 2 | Package Contents | 3 |
| What is not Covered | 2 | Assembly | 4 |
| | | Care and Cleaning | 5 |

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

1 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and the fabric to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Assembly

PLANNING ASSEMBLY

Please read this entire instruction manual prior to assembly.

Verify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.




NOTE: More than one person may be required to complete the assembly of this product.


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



_AA




_BB




_CC

| Part | Description | Quantity |
|------|---------------------------|----------|
| AA | M6x15 mm Combination Bolt | 4 |
| BB | M6x40 mm Combination Bolt | 5 |
| CC | M6 Allen Wrench | 1 |

PACKAGE CONTENTS




A




B



C



D



E

| Part | Description | Quantity |
|------|-------------------|----------|
| A | Back chair Frame | 1 |
| B | Front chair Frame | 1 |
| C | Connect bar | 2 |
| D | Seat Panel | 1 |
| E | Seat Cushion | 1 |


Assembly

1 Attaching the connect bar to the chair frames

- Attach the connect bar (C) to the front chair frame (A) and the back chair frame (B) with M6 x 15 mm bolts (AA) using the M6 Allen wrench (DD).




NOTE: Please ensure all bolts are aligned and assembled correctly. Do not tighten bolts until the frame assembly is complete.




2 Attaching the seat panel to the side panels

- Attach the seat panel (D) to the finished chair frame (A) in step 1 with M6 x 40 mm bolts (BB) using the M6 Allen Wrench (DD).
- Tighten all the bolts with the Allen wrench (DD).



3 Adding the cushions

- Place the seat cushions (E) on the chair. The chair now is ready for use.



Care and Cleaning

- ❑ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- ❑ Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- ❑ Rinse with clean water and dry with a soft, absorbent cloth towel.
- ❑ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

StyleWell™

Questions, problems, missing parts? Before returning to the store,
call StyleWell Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday


1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.

USE AND CARE GUIDE

Clovermill 4Pc Conversation Set-Table



Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this coffee table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!!

Table of Contents

| | | | |
|-------------------------------------|---|-------------------------|---|
| Table of Contents | 2 | Pre-Assembly | 3 |
| Important Safety Instructions | 2 | Planning Assembly | 3 |
| Warranty | 2 | Hardware Included | 3 |
| What is covered | 2 | Package Contents | 3 |
| What is not covered | 2 | Assembly | 4 |
| | | Care and Cleaning | 5 |

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

1 YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.


Contact the Customer Service Team at 1-877-527-0313 or visit www.homedepot.com.

Pre-Assembly

PLANNING ASSEMBLY


Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.

 **NOTE:** More than one person may be required to complete the assembly of this product.


HARDWARE INCLUDED

 **NOTE:** Hardware not shown to actual size.



| Part | Description | Quantity |
|------|-----------------------------|----------|
| AA | M6 x 20 mm combination bolt | 12 |
| BB | M6 Allen wrench | 1 |

PACKAGE CONTENTS



| Part | Description | Quantity |
|------|---------------|----------|
| A | Table top | 1 |
| B | Table leg | 4 |
| C | Leg connector | 1 |


Assembly

1 Attaching the table legs

- Attach the leg connector (C) to the table legs (B) using the M6 x 15 mm bolts (AA).




NOTE: Loosely tighten all the bolts using the Allen wrench (BB).




2 Attaching the leg connector to the table legs

- Place the table top (A) on a soft, flat non-abrasive surface. Attach the table legs (B) to the table top (A) with the M6 x 15 mm bolts (AA).
- Once all of the bolts are in place, fully tighten all the bolts.



3 Positioning the table

- Turn the table over and set it down on its legs.
- The table is now ready for use.



Care and Cleaning

- Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.

StyleWell™

Questions, problems, missing parts? Before returning to the store,
call StyleWell Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.