
Item #1004 308 336 1004 308 334 Model # FCS60619R-2PK FCS60619R-2PK-B

HAMPTON BAY

USE AND CARE GUIDE

CRESTRIDGE LOUNGE CHAIR – 2PK



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this chair. We strive to continually create quality products designed to enhance your home. Visit us onlineto see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents
Important Safety Instructions
Save These Instructions 2
Read All Instructions Before Use
Warranty
What is covered
What is not covered

Pre-Assembly	3
Planning Assembly	3
Hardware Included	4
Package Contents	4
Assembly	5
Care and Cleaning	7

Important Safety Instructions

SAVE THESE INSTRUCTIONS

WARNING: THIS CHAIR WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.

WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the chair while it is occupied. Failure to obey this caution could result in injury.

CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the chair is 250lbs (113.39Kg) for each seat.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This chair unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the chair.

3 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years, and a two year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.com.

Pre-assembly

PLANNING ASSEMBLY


Read all instructions before assembly. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)

HARDWARE INCLUDED






Assembly


Connecting The Sling Bucket, Connector Bar, And Support Bar To The Right Arm

- □ Place the right arm (B) on a soft surface.
- Attach the sling bucket (A) to the right arm (B) using M6x30 combination bolts (BB) and an M8x30 combination bolt (DD), as shown below.
- □ Attach the connector bar (D) to the right arm (B) using M6x15 combination bolts (AA).
- □ Insert the support bar (E) to the right arm (B).
- $\hfill\square$ Do not tighten all bolts at this step.



Connecting The Sling Bucket, Connector Bar, And Support Bar To The Left Arm

- □ Attach the sling bucket (A) to the left arm (C) using M6x30 combination bolts (BB) and an M8x30 combination bolt (DD), as shown below.
- □ Attach the connector bar (D) to the left arm (C) using M6x15 combination bolts (AA).
- □ Insert the support bar (E) to the left arm (C).
- $\hfill\square$ Do not tighten all bolts at this step.



Assembly (continued)




Securing The Support Bar

- □ Turn the chair right side up.
- □ Tighten the support bar (E) to the two chair arms (B&C) using M6 x25 bolts (CC).
- □ Do not fully tighten all bolts at this step.



- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (DD).
- □ Ensure all connections are secure before use.



CC

Care and Cleaning

- □ For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrrasive materials, bleach or solvents.
- □ Store the chair in a dry sheltered place when not in use.
- □ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only

Factory Chair ID #FCS60619R