


Item# 1006 471 544

Model# GG-11075-SSP

HAMPTON BAY®

USE AND CARE GUIDE

SHILOH GLEN GAZEBO



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this gazebo. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Pre-Assembly.....	3
Important Safety Instructions.....	2	Planning Assembly	3
Warranty	2	Hardware Included	3
What is covered	2	Package Contents	4
What is not covered	2	Assembly	5
		Care and Cleaning	10

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

Warranty

THIS IS A RESIDENTIAL WARRANTY ONLY AND DOES NOT APPLY TO COMMERCIAL USE

3 YEAR FRAME LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-800-841-1350 or visit www.hamptonbay.com.

Warning



WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.


This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

Pre-Assembly

PLANNING ASSEMBLY


Please read this entire instruction manual prior to assembly.

Compare all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.

**NOTE:** More than one person may be required to complete the assembly of this product.

HARDWARE INCLUDED


**NOTE:** Hardware not shown to actual size.



Part	Description	Quantity
AA	M6 x 15 mm combination bolt	52
BB	M6 x 30 mm combination bolt	8
CC	M6 x 45 mm combination bolt	4
DD	M6 nut	12
EE	Stake	8
FF	M6 Allen wrench	1
GG	M6 Hex wrench	1

Pre-Assembly (continued)


PACKAGE CONTENTS



Part	Description	Quantity
A	Post	4
B	Short beam	4
C	Long beam	4
D	Top support bar 1	4
D1	Top support bar 2	4
E	Top support bar 3	2
F	Top support bar 4	2
G	Top plate	1
H	Leg base plate	4
I	U shape clip 1	4
J	U shape clip 2	4
K	U shape connector	8
L	Big canopy cover	1
L1	Small canopy cover	1
M	Mosquito Net 1	2
M1	Mosquito Net 2	2
N	Leg cloth	4


1 Attaching the beams

- Attach the short beams (B) and long beams (C) with U shape connector (K) using M6 x 45 mm combination bolts (CC) and M6 nuts (DD), M6 x 15 mm combination bolts (AA). Fully tighten all the bolts with M6 Allen wrench (FF).
- Attach the U shape clips 2 (J) to the U shape connector (K) using M6 x 15 mm combination bolts (AA). Loosely tighten all the bolts with M6 Allen wrench (FF).



2 Attaching the U shape clips and leg base plates to the posts


- Attach the U shape clips 1 (I) and leg base plates (H) to the posts (A) using M6 x 15 mm combination bolts (AA) with M6 Allen wrench (FF).
- Fully tighten the bolts on the leg base plates (H), and loosely tighten the U shape clips (I).



Assembly (continued)


3 Attaching the long beams to the posts

- Attach the long beams (C) to the posts (A) using M6 x 15 mm combination bolts (AA).
- Fully tighten all the bolts with M6 Allen wrench (FF).



4 Attaching one short beam to the posts


- Attach one short beam (B) to the posts (A) using M6 x 15 mm combination bolts (AA).
- Fully tighten all the bolts with M6 Allen wrench (FF).



Assembly (continued)


5 Attaching another short beam to the posts

- Attach the another beam (B) to the posts (A) using M6 x 15 mm combination bolts (AA).
- Fully tighten all the bolts with M6 Allen wrench (FF).



6 Attaching the top support bar 4 to the beams


- Insert the top support bars 4 (F) into the top plate (G).
- Attach the top support bars 4 (F) to the long beams (C) using M6 x 30 mm combination bolts (BB) and M6 nuts (DD).



Assembly (continued)


7 Attaching the top support bar 3 to the beams

- Insert the top support bars 3 (E) into the top plate (G).
- Attach the top support bars 3 (E) to the short beams (B) using M6 x 30 mm combination bolts (BB) and M6 nuts (DD).




8 Attaching the top support bar 1 to top support bar 2

- Attach the top support bars 1 (D) to the top support bars 2 (D1) using M6 x 15 mm combination bolts (AA).
- Fully tighten all the bolts with M6 Allen wrench (FF).




9 Attaching the top support bars 2 to the posts

- Insert the top support bars 1 (D) into the top plate (G).
- Attach the top support bars 2 (D1) to the posts (A) using M6 x 30 mm combination bolts (BB) and M6 nuts (DD).



10 Insert the canopy covers into the frame


- Insert the big canopy cover (L) to the frame according to image below.
- Insert the small canopy cover (L1) to the frame according to image below..



Assembly (continued)

11 Hang the mosquito net onto the beams

- Hang the mosquito nets (M and M1) onto the beams (B and C) according to image below.
- Hang the leg cloths (N) onto the four posts (A).
- Adjust position of gazebo and insert the stakes (EE) into the two holes of leg base plates (H).



Care and Maintenance

- For cleaning, use a mild detergent solution, rinse with water, and allow to air dry. Do not use acetone, abrasive, or other special detergents as they would be harmful to the product's finish.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.