

EASED EDGE STAIR TREAD

End caps are used to fill the gap between the floor and carpet, hearths or against sliding doors.

