

For best results: The Melnor 20 piece repair kit is used to get you back to your watering fast! It contains 14 washers of various sizes to be used to prevent or stop between connector leaks, 4 screens to assist in preventing build up and 2 end caps to keep dirt and water out. Place washers or screens between your faucet and hose, or your hose and preferred hose accessory such as a nozzle, sprinkle or shower wand.

