




Identify and remove your faucet's aerator If your faucet has an aerator, Unscrew it as shown below in figure A1 and A2 (Your aerator may look different)



Important: The aerator has a rubber washer that get stuck to the metal faucet. Be sure to remove rubber washer from the faucet.





Step Ready to Attach Connector to Faucet



Grip connector with one hand and with free hand, push down outer ring



Keeping outer ring in the down position ,place connector under the faucet and push it up onto the faucet to fit securely in place.

Important : To avoid damage to the faucet connector , you must push down the outer ring before pushing up the connector onto the faucet.



Your **CLEAR O** pitcher has an intelligent Filter indicator built into the filter cover that automatically activates to the flow meter indicator and resets it every time you install a new filter.

Making it easy to know exactly when to replace the filter.





Never use hot water (above 85 F)



Open the faucet enough so that water flows through the hose.

Important: To avoid overflow ,do not use too much water pressure.

Fill the pitcher to the MAX line .Do not overfill.

Discard the first 3 pitchers of filtered water to flush the system.

Replace filter



Once the pitcher is filled with desired amount of water ,again push down outer ring and then pull down connector to disconnect from the faucet.

Wipe the connect to dry.





When finished , insert quick- connect house and connector into storage compartment.

Keep new faucet adapter attached in place.







To remove the filter, lift the filter ,lift the lid and open the lid

Turn the bar on the filter counter clockwise to the unlocked position. Keep turning the bar until filter released.

Pull out the filter and discard.