


INSTRUCTIONS FOR TWIST LOCK TENSION ROD



1. TWIST TO UNLOCK
2. EXTEND
3. TWIST TO LOCK