

SUN SHADE SAIL – USE & CARE MANUAL

1. INSTALLATION INSTRUCTIONS

A. Choose Your Location

- Select a location that allows for at least a 20°-30° angle for water runoff.
- Ensure the area is clear of sharp objects or abrasive surfaces.

B. Hardware Required (Not included unless specified):

- Turnbuckles
- Pad eyes or eye bolts
- Snap hooks or carabiners
- Ropes or tensioning cords

C. Installation Steps

1. Measure your area and install secure mounting points (walls, poles, or posts).
2. Attach each corner of the sail to the mounting point using appropriate hardware.
3. Tension the sail firmly to avoid sagging but do not overstretch.
4. Allow for a slope to enable rainwater drainage.

Warning: Never install the sail near open flames or heat sources.

2. CARE & MAINTENANCE

Cleaning:

- Clean using mild detergent and water with a soft brush.
- Do not use bleach, harsh chemicals, or pressure washers.
- Rinse thoroughly and allow to air dry.

Storage:

- Remove during severe weather, snow, or storms.
- Store in a cool, dry place when not in use for extended periods.

Inspection:

- Regularly inspect seams, corners, and mounting hardware.
- Replace or repair any damaged parts before reinstalling.

3. SAFETY WARNINGS

- Not designed to support weight—do not hang objects from the sail.
- Not a waterproof or rainproof product unless specifically stated.
- UV resistance may degrade over time; consider replacement after 3-5 years of use.

4. WARRANTY INFORMATION

The product is covered 1-year warranty for manufacturing defects.