


Toiletsaber® Use and Care Manual

Toiletsaber® was specifically designed to clear visible toilet clogs (paper & poop), which are the most common. If there is no visible clog, this means the obstruction is farther back in the waste pipe, and it may not be within reach of a Toiletsaber®. In this rare instance, a toilet plunger or toilet auger would be recommended.

Please follow these Toiletsaber® instructions for best results on visible toilet clogs:

1. Raise water to this level by flushing or using a container. Tip: Add 6-8 fl oz of any liquid soap (bath foam, shampoo, or dish soap) to the water.



2. Rake **ALL** of the excess waste away from the hole until you can feel the porcelain below.



3. Turn over and poke through the remaining clog. Clean with a thick disposable wet wipe or cloth and disinfect using bleach.



Tip: If the clog remains, keep repeating steps 1, 2, and 3 until the clog is cleared.

Toiletsaber® Instruction Video

<https://www.mrsparkle.com/pages/toiletsaber-instruction-video>

Toiletsaber® Customer Support

<https://www.mrsparkle.com/pages/contact-us>